
ECS 323: Control Systems

Planar VTOL System

Design Study

Submitted by: Jaydev Singh Rao

Roll No. : 19147

Contents

| | |
|---|-----------|
| 1. Design Study Description | 3 |
| 2. Kinetic Energy | 4 |
| 3. Equations of Motion | 5 |
| 4. Linearize Equations of Motion | 7 |
| 5. Transfer Function Model | 9 |
| 6. State Space Model | 11 |

1. Design Study Description

In this design study we need to design a control system for a planar VTOL system with the given parameters [1]:

- $M_c = 2 \text{ kg}$
- $J_c = 0.009 \text{ kg m}^2$
- $m_l = 0.3 \text{ kg}$
- $m_r = 0.3 \text{ kg}$
- $d = 0.28 \text{ m}$
- $\mu = 0.21 \text{ kg s}^{-1}$




Figure 1: Planar VTOL System

2. Kinetic Energy

The postions of the various components of the VTOL are given by:

$$\begin{aligned}\mathbf{p}_c &= (z_v, h) \\ \mathbf{p}_l &= (z_v - d \cos \theta, h - d \sin \theta) \\ \mathbf{p}_r &= (z_v + d \cos \theta, h + d \sin \theta)\end{aligned}$$

So, the velocities can be written as:

$$\begin{aligned}\mathbf{v}_c &= (\dot{z}_v, \dot{h}) \\ \mathbf{v}_l &= (\dot{z}_v + d\dot{\theta} \sin \theta, \dot{h} - d\dot{\theta} \cos \theta) \\ \mathbf{v}_r &= (\dot{z}_v - d\dot{\theta} \sin \theta, \dot{h} + d\dot{\theta} \cos \theta)\end{aligned}$$

Kinetic energy of the centerpod is given by:

$$K_{pod} = \frac{1}{2} m_c \mathbf{v}_c^T \mathbf{v}_c + \frac{1}{2} \boldsymbol{\omega}_c^T J_c \boldsymbol{\omega}_c = \frac{1}{2} m_c (\dot{z}_v^2 + \dot{h}^2) + \frac{1}{2} J_c \dot{\theta}^2 \quad (1)$$

Kinetic energy of the left and right rotors is given by:

$$\begin{aligned}K_{rotors} &= \frac{1}{2} m_l \mathbf{v}_l^T \mathbf{v}_l + \frac{1}{2} m_r \mathbf{v}_r^T \mathbf{v}_r \\ &= \frac{1}{2} m_l (\dot{z}_v + d\dot{\theta} \sin \theta)^2 + \frac{1}{2} m_l (\dot{h} - d\dot{\theta} \cos \theta)^2 \\ &\quad + \frac{1}{2} m_r (\dot{z}_v - d\dot{\theta} \sin \theta)^2 + \frac{1}{2} m_r (\dot{h} + d\dot{\theta} \cos \theta)^2 \\ &= \frac{1}{2} (m_l + m_r) (\dot{z}_v^2 + \dot{h}^2) + \frac{1}{2} (m_l + m_r) d^2 \dot{\theta}^2 \\ &\quad + (m_l - m_r) (\dot{z}_v \sin \theta - \dot{h} \cos \theta) d \dot{\theta}\end{aligned} \quad (2)$$

Now, the total kinetic energy of the VTOL will be given by the sum of (1) and (2):

$$\begin{aligned}K_V &= K_{pod} + K_{rotors} \\ &= \frac{1}{2} (m_c + m_l + m_r) (\dot{z}_v^2 + \dot{h}^2) + \frac{1}{2} (m_l d^2 + m_r d^2 + J_c) \dot{\theta}^2 \\ &\quad + (m_l d - m_r d) (\dot{z}_v \sin \theta - \dot{h} \cos \theta) \dot{\theta}\end{aligned} \quad (3)$$

As in the given parameters $m_l = m_r$, so the last term in the kinetic energy is zero and will be ignored in the rest of the report.

3. Equations of Motion

- (a) Now in order to determine the equations of motion of the VTOL, we first write its potential energy. The potential energy is due to the gravitational potential and can be written as the sum of potential energies of the individual components:

$$P_V = m_c gh + m_l gh + m_r gh = (m_c + m_l + m_r)gh \quad (4)$$

- (b) Now as we are only considering the dynamics of the VTOL and not of the target so the generalized coordinates can be defined as:

$$\mathbf{q} = \begin{pmatrix} z_v \\ h \\ \theta \end{pmatrix}$$

Also as it is given in the project objective, the damping forces in the system are due to the momentum drag which is caused by the change in direction of the air when it flows through the rotors. This momentum drag can be modeled as $F_{drag} = -\mu \dot{z}_v$. So, we can write the dissipative (drag) forces as:

$$-B\dot{\mathbf{q}} = - \begin{pmatrix} \mu \dot{z}_v \\ 0 \\ 0 \end{pmatrix} = - \begin{pmatrix} \mu & 0 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{pmatrix} \begin{pmatrix} \dot{z}_v \\ \dot{h} \\ \dot{\theta} \end{pmatrix}$$

- (c) The total force on the COM of the VTOL is given by $F = f_l + f_r$. The torque due to the left rotor is $\tau_l = -f_l d$ (using right handed coordinates) and the torque due to the right rotor is $\tau_r = f_r d$. Hence, the total torque about the COM of the VTOL is $\tau = (f_r - f_l)d$. So, we can write the generalized forces as:

$$\Phi = \begin{pmatrix} -F \sin \theta \\ F \cos \theta \\ \tau \end{pmatrix} = \begin{pmatrix} -(f_r + f_l) \sin \theta \\ (f_r + f_l) \cos \theta \\ (f_r - f_l)d \end{pmatrix}$$

- (d) Using the kinetic and the potential energies (3) and (4) we can write the Lagrangian as:

$$\mathcal{L} = K_V - P_V = \frac{1}{2} M_V (\dot{z}_v^2 + \dot{h}^2 - 2gh) + \frac{1}{2} J_V \dot{\theta}^2$$

Here, $M_V \equiv (m_c + m_l + m_r)$ and $J_V \equiv (m_l d^2 + m_r d^2 + J_c)$. Now, we can write:

$$\frac{\partial \mathcal{L}}{\partial \dot{\mathbf{q}}} = \begin{pmatrix} M_V \dot{z}_v \\ M_V \dot{h} \\ J_V \dot{\theta} \end{pmatrix}$$

And,

$$\frac{\partial \mathcal{L}}{\partial \mathbf{q}} = \begin{pmatrix} 0 \\ -M_V g \\ 0 \end{pmatrix}$$

Writing the Euler-Lagrange equations in matrix form:

$$\begin{aligned}
 \frac{d}{dt} \left(\frac{\partial \mathcal{L}}{\partial \dot{\mathbf{q}}} \right) - \frac{\partial \mathcal{L}}{\partial \mathbf{q}} &= \mathbf{\Phi} - B\dot{\mathbf{q}} \\
 \Rightarrow \begin{pmatrix} M_V \ddot{z}_v \\ M_V \ddot{h} \\ J_V \ddot{\theta} \end{pmatrix} - \begin{pmatrix} 0 \\ -M_V g \\ 0 \end{pmatrix} &= \begin{pmatrix} -F \sin \theta \\ F \cos \theta \\ \tau \end{pmatrix} - \begin{pmatrix} \mu \dot{z}_v \\ 0 \\ 0 \end{pmatrix} \\
 \Rightarrow \boxed{\begin{pmatrix} M_V \ddot{z}_v \\ M_V \ddot{h} \\ J_V \ddot{\theta} \end{pmatrix} = \begin{pmatrix} -\mu \dot{z}_v - F \sin \theta \\ -M_V g + F \cos \theta \\ \tau \end{pmatrix}} & \quad (5)
 \end{aligned}$$

4. Linearize Equations of Motion

- (a) First we determine the equilibrium points of the equations of motion (5) of the VTOL. At this point there is no motion in the system. This means:

$$\dot{\mathbf{q}} = \begin{pmatrix} \dot{z}_v \\ \dot{h} \\ \dot{\theta} \end{pmatrix} = \begin{pmatrix} 0 \\ 0 \\ 0 \end{pmatrix}$$

And consequently,

$$\ddot{\mathbf{q}} = 0 \implies \begin{pmatrix} M_V \ddot{z}_v \\ M_V \ddot{h} \\ J_V \ddot{\theta} \end{pmatrix} = 0$$

$$\begin{pmatrix} -\mu \dot{z}_v - F \sin \theta \\ M_V g + F \cos \theta \\ \tau \end{pmatrix} = 0 \implies \begin{pmatrix} -F \sin \theta \\ -M_V g + F \cos \theta \\ \tau \end{pmatrix} = 0$$

The solutions of the above equations are given by, $\theta_e = 0$ or $\theta_e = \pi$ and due to this $F_e = M_V g$ or $F_2 = -M_V g$ and $\tau_e = 0$. The values of z_e and h_e can be anything.

But taking the practical consideration that the rotors are able to rotate in only one direction the case where $\theta = \pi$ and $F_e = -M_V g$, the rotors can not generate a positive force in the opposite direction of the direction of lift. So, we will drop this case.

- (b) In order to linearize the equations, we first write the equations seperately in the form:

$$\ddot{z}_v = -\frac{\mu}{M_V} \dot{z}_v - \frac{F}{M_V} \sin \theta$$

$$\ddot{h} = -g + \frac{F}{M_V} \cos \theta$$

$$\ddot{\theta} = \frac{1}{J_c} \tau$$

Now, we define:

$$\tilde{z} \equiv z_v - z_v^{(e)}, \tilde{h} \equiv h - h_e, \tilde{\theta} \equiv \theta - \theta_e, \tilde{F} \equiv F - F_e, \tilde{\tau} \equiv \tau - \tau_e = \tau$$

Also, we can note that as $\dot{\mathbf{q}}_e = 0$ and $\ddot{\mathbf{q}}_e = 0$, so we can write:

$$\dot{\tilde{z}} = \dot{z}_v, \ddot{\tilde{z}} = \ddot{z}_v$$

$$\dot{\tilde{h}} = \dot{h}, \ddot{\tilde{h}} = \ddot{h}$$

$$\dot{\tilde{\theta}} = \dot{\theta}, \ddot{\tilde{\theta}} = \ddot{\theta}$$

Now we linearize the non-linear terms in these equations as follows:

$$\begin{aligned}
\frac{\mu}{M_V} \dot{z}_v &\approx \frac{\mu}{M_V} \dot{z}_v^{(e)} + \left. \frac{\partial}{\partial \dot{z}_v} \left(\frac{\mu}{M_V} \dot{z}_v \right) \right|_{eq.} (\dot{z}_v - \dot{z}_v^{(e)}) \\
&= \frac{\mu}{M_V} \ddot{z} \\
\frac{F}{M_V} \sin \theta &\approx \frac{F}{M_V} \sin \theta_e + \left. \frac{\partial}{\partial \theta} \left(\frac{F}{M_V} \sin \theta \right) \right|_{eq.} (\theta - \theta_e) \\
&= \frac{F_e}{M_V} \tilde{\theta} \cos \theta_e \\
&= g \tilde{\theta} \\
\frac{F}{M_V} \cos \theta &\approx \frac{F}{M_V} \cos \theta_e + \left. \frac{\partial}{\partial \theta} \left(\frac{F}{M_V} \cos \theta \right) \right|_{eq.} (\theta - \theta_e) \\
&= \frac{F}{M_V} + \frac{F_e}{M_V} \tilde{\theta} \sin \theta_e \\
&= \frac{F}{M_V} \\
&= \frac{\tilde{F}}{M_V} + g
\end{aligned}$$

So, the linearized equations of motion are:

$$\begin{aligned}
\ddot{z} &= -\frac{\mu}{M_V} \dot{z} - g \tilde{\theta} \\
\ddot{h} &= \frac{\tilde{F}}{M_V} \\
\ddot{\theta} &= \frac{1}{J_c} \tilde{\tau}
\end{aligned} \tag{6}$$

- (c) The equations of motion can only be feedback linearized if we can write the equations in the form given below where $y(t)$ is the output and $u(t)$ is the input with the function $g(y, \dot{y})$ giving the non-linear terms.

$$a\ddot{y} + b\dot{y} + cy = g(y, \dot{y}) + u(t)$$

But in the case of the equations of motion of the planar VTOL given by (5), the non-linearity is present in the input term itself (F is the input), and hence we can't separately define $g(y, \dot{y})$. Hence, the system can not be feedback linearized.

5. Transfer Function Model

- (a) We have the linearized equations of motion given in (6). If we take the laplace transform of those equations we get the following:

$$\begin{aligned} s^2 \tilde{Z}(s) &= -\frac{\mu}{M_V} s \tilde{Z}(s) - g \tilde{\Theta}(s) \\ s^2 \tilde{H}(s) &= \frac{1}{M_V} \tilde{F}(s) \\ s^2 \tilde{\Theta}(s) &= \frac{1}{J_c} \tilde{\tau}(s) \end{aligned}$$

- (b) For longitudinal dynamics we have the following equation:

$$\begin{aligned} s^2 \tilde{H}(s) &= \frac{1}{M_V} \tilde{F}(s) \\ \implies \tilde{H}(s) &= \frac{1}{s^2 M_V} \tilde{F}(s) \end{aligned}$$

Hence, in the longitudinal dynamics we have $\tilde{F}(s)$ as the input variable and $\tilde{H}(s)$ as the output with transfer function $\frac{1}{s^2 M_V}$.

- (c) For lateral dynamics first we have the equation for $\tilde{\Theta}(s)$:

$$\begin{aligned} s^2 \tilde{\Theta}(s) &= \frac{1}{J_c} \tilde{\tau}(s) \\ \implies \tilde{\Theta}(s) &= \frac{1}{s^2 J_c} \tilde{\tau}(s) \end{aligned}$$

And, also we have the equation for $\tilde{Z}(s)$ given by:

$$\begin{aligned} s^2 \tilde{Z}(s) &= -\frac{\mu}{M_V} s \tilde{Z}(s) - g \tilde{\Theta}(s) \\ \implies \tilde{Z}(s) + \frac{\mu}{s M_V} \tilde{Z}(s) &= -\frac{g}{s^4 J_c} \tilde{\tau}(s) \\ \implies \tilde{Z}(s) &= -\frac{\frac{g}{s^4 J_c} \tilde{\tau}(s)}{1 + \frac{\mu}{s M_V}} \\ \implies \tilde{Z}(s) &= -\frac{M_V g}{s^3 J_c (s M_V + \mu)} \tilde{\tau}(s) \end{aligned}$$

Hence, in the lateral dynamics we have $\tilde{\tau}(s)$ is the input variable, $\tilde{\Theta}(s)$ is the intermediate variable with transfer function $\frac{1}{s^2 J_c}$ and $\tilde{Z}(s)$ is the output variable with transfer function $-\frac{M_V g}{s^3 J_c (s M_V + \mu)}$.

(d) The block diagrams of open loop longitudinal and lateral systems are:




Figure 2: Longitudinal open loop system




Figure 3: Lateral open loop system

6. State Space Model

- (a) For the longitudinal dynamics we define the state of the system as $\tilde{x}_{lon} = \begin{pmatrix} \tilde{h} & \dot{\tilde{h}} \end{pmatrix}^T$, the input as $\tilde{u}_{lon} = \tilde{F}$ and the output as $\tilde{y}_{lon} = \tilde{h}$. Now we can write:

$$\begin{aligned} \dot{\tilde{x}}_{lon} &= \begin{pmatrix} \dot{\tilde{h}} \\ \ddot{\tilde{h}} \end{pmatrix} = \begin{pmatrix} \dot{\tilde{h}} \\ \frac{\tilde{F}}{M_V} \end{pmatrix} \\ \Rightarrow \dot{\tilde{x}}_{lon} &= \begin{pmatrix} \dot{\tilde{h}} \\ \frac{\tilde{u}_{lon}}{M_V} \end{pmatrix} = \begin{pmatrix} 0 & 1 \\ 0 & 0 \end{pmatrix} \begin{pmatrix} \tilde{h} \\ \dot{\tilde{h}} \end{pmatrix} + \begin{pmatrix} 0 \\ \frac{1}{M_V} \end{pmatrix} \tilde{u}_{lon} \\ \Rightarrow \dot{\tilde{x}}_{lon} &= A\tilde{x}_{lon} + B\tilde{u}_{lon} \end{aligned}$$

Similary for the output we have:

$$\begin{aligned} \tilde{y}_{lon} &= \tilde{h} \\ \Rightarrow \tilde{y}_{lon} &= \begin{pmatrix} 1 & 0 \end{pmatrix} \begin{pmatrix} \tilde{h} \\ \dot{\tilde{h}} \end{pmatrix} + \begin{pmatrix} 0 \end{pmatrix} \tilde{u}_{lon} \\ \Rightarrow \tilde{y}_{lon} &= C\tilde{x}_{lon} + D\tilde{u}_{lon} \end{aligned}$$

- (b) For the lateral dynamics we define the state as $\tilde{x}_{lat} = \begin{pmatrix} \tilde{z} & \tilde{\theta} & \dot{\tilde{z}} & \dot{\tilde{\theta}} \end{pmatrix}^T$ with the input $\tilde{u}_{lat} = \tilde{\tau}$ and output $\tilde{y}_{lat} = \begin{pmatrix} \tilde{z} & \tilde{\theta} \end{pmatrix}^T$. So for this we have:

$$\begin{aligned} \dot{\tilde{x}}_{lat} &= \begin{pmatrix} \dot{\tilde{z}} \\ \dot{\tilde{\theta}} \\ \ddot{\tilde{z}} \\ \ddot{\tilde{\theta}} \end{pmatrix} = \begin{pmatrix} \dot{\tilde{z}} \\ \dot{\tilde{\theta}} \\ -\frac{\mu}{M_V}\dot{\tilde{z}} - g\tilde{\theta} \\ \frac{1}{J_c}\tilde{\tau} \end{pmatrix} \\ \Rightarrow \dot{\tilde{x}}_{lat} &= \begin{pmatrix} 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & -g & -\frac{\mu}{M_V} & 0 \\ 0 & 0 & 0 & 0 \end{pmatrix} \begin{pmatrix} \tilde{z} \\ \tilde{\theta} \\ \dot{\tilde{z}} \\ \dot{\tilde{\theta}} \end{pmatrix} + \begin{pmatrix} 0 \\ 0 \\ 0 \\ \frac{1}{J_c} \end{pmatrix} \tilde{\tau} \\ \Rightarrow \dot{\tilde{x}}_{lat} &= A\tilde{x}_{lat} + B\tilde{u}_{lat} \end{aligned}$$

Similary, for the output we have:

$$\begin{aligned} \tilde{y}_{lat} &= \begin{pmatrix} \tilde{z} \\ \tilde{\theta} \end{pmatrix} = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \end{pmatrix} \begin{pmatrix} \tilde{z} \\ \tilde{\theta} \\ \dot{\tilde{z}} \\ \dot{\tilde{\theta}} \end{pmatrix} + \begin{pmatrix} 0 \end{pmatrix} \tilde{\tau} \\ \Rightarrow \tilde{y}_{lat} &= C\tilde{x}_{lat} + D\tilde{u}_{lat} \end{aligned}$$

References

- [1] Randal W Beard, Timothy W. McLain, Cammy Peterson, Marc Killpack (2021), “Introduction to Feedback Control using Design Studies”, <http://controlbook.byu.edu/doku.php>