

# Q1 PSU Display Screen

Mon Nov 16 1998

11:38:13

He U10  
Trend N2  
ILX Temp  
Cool

Command Line

psu:standby

Cursor and  
F4 to shutdown

Overall State NORMAL  
N2 system state N2COLD  
He System state HeCOLD  
PSU State Enabled

Main Power

MPS not ready

Setcur input

Setcur readback

PSU polarity

PSU ramp rate

PSU cur readback

PSU o/p voltage

Loc / Rem status

Standby

Ready

0.00 A

0.00 A

+ve

1.55 A/sec

0.00 A

0.14 V

REMOTE

Control Rack I/L

Panic / Door

MPS waterflow

MPS overtemp

Phase failure

Reg mod failure

Max Current Set

F6: ALARM POINT

F7: ALARM ACK