

PO Box 518  
620 Applegate St.  
Philomath, OR 97370



(541) 929-5650  
Fax (541) 929-5277  
[www.wetlabs.com](http://www.wetlabs.com)

## ECO CDOM Fluorometer Characterization Sheet

Date: 3/4/2016

S/N: BBFL2WB-1307

CDOM concentration expressed in ppb can be derived using the equation:

$$\text{CDOM (ppb)} = \text{Scale Factor} * (\text{Output} - \text{Dark Counts})$$

<b>Dark Counts</b>	<b>Digital</b>
<b>Scale Factor (SF)</b>	48 counts
<b>Maximum Output</b>	0.0864 ppb/count
<b>Resolution</b>	4130 counts
	1.5 counts
Ambient temperature during characterization	22.5 °C

**Dark Counts:** Signal output of the meter in clean water with black tape over detector.

**SF:** Determined using the following equation:  $SF = x \div (\text{output} - \text{dark counts})$ , where  $x$  is the concentration of the solution used during instrument characterization. SF is used to derive instrument output concentration from the raw signal output of the fluorometer.

**Maximum Output:** Maximum signal output the fluorometer is capable of.

**Resolution:** Standard deviation of 1 minute of collected data.