



For participants only. Not for public distribution.

**Note #41**  
**Move Server Design Specification**

Achut Reddy  
Last revise






FIGURE 1 - Move server block diagram

#### Receive Thread

This thread simply loops waiting for command messages. When a command is received, it sim

The Move server does not issue commands to the Brake and Th