

# Serial Commands for Countdown Display

Joshua Bays (UAH ETLC)

## Contents

<b>1</b>	<b>setc</b>	<b>2</b>
<b>2</b>	<b>sett</b>	<b>2</b>
<b>3</b>	<b>dpyt</b>	<b>2</b>
<b>4</b>	<b>swon</b>	<b>2</b>
<b>5</b>	<b>swoff</b>	<b>2</b>
<b>6</b>	<b>togc</b>	<b>2</b>
<b>7</b>	<b>togt</b>	<b>3</b>
<b>8</b>	<b>toga</b>	<b>3</b>
<b>9</b>	<b>pzt</b>	<b>3</b>
<b>10</b>	<b>pzs</b>	<b>3</b>
<b>11</b>	<b>sec</b>	<b>3</b>
<b>12</b>	<b>shd</b>	<b>3</b>
<b>13</b>	<b>rbt</b>	<b>3</b>

## **setc**

**Ex:** *setc 12252023201545*

Set the clock to a given time in the MMDDYYYYhhmmss format.

(Example above sets the clock to 12.25.2023 at 8:15:45 PM)

## **sett**

**Ex:** *sett 80*

Set the timer to a specific time in the hh:mm:ss format.

(Example above sets a timer for 1 hour and 20 minutes)

## **dpyt**

**Ex:** *dpyt 80*

Set the timer to a specific time in the hh:mm:ss format, but not start the timer (displays the timer).

(Example above displays a timer for 1 hour and 20 minutes)

## **swon**

**Ex:** *swon*

Turn on the stopwatch. The stopwatch will display automatically.

## **swoff**

**Ex:** *swoff*

Turn off the stopwatch. The stopwatch will stop displaying automatically.

## **togc**

**Ex:** *togc*

Toggle the clock from displaying.

## **togt**

**Ex:** *togt*

Toggle the timer from displaying.

## **toga**

**Ex:** *toga*

Toggle the alarm sound.

## **pzt**

**Ex:** *pzt*

Pause/Resume the timer.

## **pzs**

**Ex:** *pzs*

Pause/Resume the stopwatch

## **sec**

**Ex:** *sec*

Toggle the seconds display on the clock

## **shd**

**Ex:** *shd*

Shuts the entire computer down (sudo/admin access required).

## **rbt**

**Ex:** *rbt*

Reboots the entire computer (sudo/admin access required).