




## LineSensor




## Buzzer




## Capasitor




## SDcard




## Gyro Sensor




## encoder




## potentio




## LCD




## Rotary SW






## Button




## LEDs




Power supply




## Reset Switch



## Mode selection



foward



# 5ch Motor Driver

backward

