

RPI Imager:

<https://www.raspberrypi.com/software/>

Wybieramy następujący SW:



Raspberry Pi OS Lite (64-bit)

A port of Debian Bullseye with no desktop environment (Compatible with Raspberry Pi 3/4/400)

Released: 2023-05-03

Cached on your computer

Zrzut konfiguracji dostępny poniżej

SSID: lokalne wifi, nazwa i hasło

W przypadku błędu wgrać obraz drugi raz

Włożyć kartę do slotu na płytce, podłączyć zasilanie

Na hoście odpalić

```
$ ping pi4@raspberrypi.local
```

I czekać aż będzie odpowiedź (może potrwać chwilę)

Następnie zalogować się przez SSH:

```
$ ssh pi4@raspberrypi.local
```

Podać hasło ustalone w konfiguracji

Image customization options to always use ▼

☒ Set hostname: raspberrypi .local☒ Enable SSH☒ Use password authentication☐ Allow public-key authentication only

Set authorized_keys for 'pi4': _____

☒ Set username and password

Username: pi4

Password: _____

☒ Configure wireless LAN

SSID: Bulbazaur

☐ Hidden SSID

Password: _____

☐ Show password

Wireless LAN country: PL ▼

☒ Set locale settings

Time zone: Europe/Warsaw ▼

Keyboard layout: us ▼

Persistent settings

☐ Play sound when finished☒ Eject media when finished☒ Enable telemetry

SAVE