



ARM Instructions Worksheet #6

Conditional Branch

Signed versus Unsigned

Prerequisite Reading: Chapter 6

Revised: March 25, 2020

Objectives: To use the web-based simulator ("CPULator") to better understand ...

1. Single versus unsigned conditional branch instructions.

To do offline: Answer the questions that follow the listing below. (Numbers at far left are memory addresses.)

```
.syntax unified
.global _start

00000000 _start: LDR    R0,=0xFFFFFFFF // *** EXECUTION STARTS HERE ***
00000004 loop:  LDR    R1,=0x11111 // Turn on all flags
00000008          CMP    R0,1
0000000C test1:  BLO    test2 // Branch if R0 < 1 (unsigned)
00000010          SUB    R1,R1,0x1000 // Did not branch: Turn off LO flag
00000014 test2:  BHI    test3 // Branch if R0 > 1 (unsigned)
00000018          SUB    R1,R1,0x0100 // Did not branch: Turn off HI flag
0000001C test3:  BLT    test4 // Branch if R0 < +1 (signed)
00000020          SUB    R1,R1,0x0010 // Did not branch: Turn off LT flag
00000024 test4:  BGT    test5 // Branch if R0 > +1 (signed)
00000028          SUB    R1,R1,0x0001 // Did not branch: Turn off GT flag
0000002C test5:  BEQ    next // Branch if R0 == 1
00000030          SUB    R1,R1,0x00001 // Did not branch: Turn off EQ flag
00000034 next:  ADD    R0,R0,1 // Increment R0
00000038          B      loop // and repeat.

.end
```

Note: The least-significant four hex digits of register R1 will be used to indicate which conditions were satisfied according to the table shown at the right:

R1 contents	LO	HI	LT	GT	EQ
0x00010000	✓				
0x00001000		✓			
0x00000100			✓		
0x00000010				✓	
0x00000001					✓

What is in R0 the 1st time execution arrives at address 00000038₁₆?

R0 (as unsigned decimal)
4294967295

R0 (as signed decimal)
-1

Which conditions does R1 indicate as true for R0 compared to 1?

LO ☐ EQ ☐ HI ☒ LT ☒ GT ☐

What is in R0 the 2nd time execution arrives at address 00000038₁₆?

R0 (as unsigned decimal)
0

R0 (as signed decimal)
0

Which conditions does R1 indicate as true for R0 compared to 1?

LO ☒ EQ ☐ HI ☐

LT ☒ EQ ☐ GT ☐

What is in R0 the 3rd time execution arrives at address 00000038₁₆?

R0 (as unsigned decimal)
1

R0 (as signed decimal)
1

Which conditions does R1 indicate as true for R0 compared to 1?

LO ☐ EQ ☒ HI ☐

LT ☐ EQ ☒ GT ☐

What is in R0 the 4th time execution arrives at address 00000038₁₆?

R0 (as unsigned decimal)
2

R0 (as signed decimal)
2

Which conditions does R1 indicate as true for R0 compared to 1?

LO ☐ EQ ☐ HI ☒

LT ☐ EQ ☐ GT ☒

Getting ready: Now use the simulator to collect the following information and compare to your earlier answers.

1. Click [here](#) to open a browser for the ARM instruction simulator with pre-loaded code.
1. In the “Disassembly” window, click in the grey area left of the ADD instruction. The red dot (●) is a breakpoint where the simulation will pause *before* executing this instruction.

Notes:

1. The BLO instruction in the “Editor” window will appear as an equivalent BCC instruction in the “Disassembly window.
2. You can change the number format in the “Settings” window between hex, unsigned decimal and signed decimal as needed.

Step 1: Press F3 exactly once to run the simulation and stop at the breakpoint.

What is in R0 the 1st time execution arrives at address 00000038₁₆?

R0 (as unsigned decimal)
4294967295

R0 (as signed decimal)
-1

Which conditions does R1 indicate as true for R0 compared to 1?

LO ☐ EQ ☐ HI ☒

LT ☒ EQ ☐ GT ☐

Step 2: Press F3 exactly once to run the simulation and stop at the breakpoint.

What is in R0 the 2nd time execution arrives at address 00000038₁₆?

R0 (as unsigned decimal)
0

R0 (as signed decimal)
0

Which conditions does R1 indicate as true for R0 compared to 1?

LO ☒ EQ ☐ HI ☐

LT ☒ EQ ☐ GT ☐

10100

Step 3: Press F3 exactly once to run the simulation and stop at the breakpoint.

What is in R0 the 3rd time execution arrives at address 00000038₁₆?

R0 (as unsigned decimal)
1

R0 (as signed decimal)
1

Which conditions does R1 indicate as true for R0 compared to 1?

LO ☐ EQ ☒ HI ☐

LT ☐ EQ ☒ GT ☐

Step 4: Press F3 exactly once to run the simulation and stop at the breakpoint.

What is in R0 the 4th time execution arrives at address 00000038₁₆?

R0 (as unsigned decimal)
2

R0 (as signed decimal)
2

Which conditions does R1 indicate as true for R0 compared to 1?

LO ☐ EQ ☐ HI ☒

LT ☐ EQ ☐ GT ☒

1010