



Note:
 Amplifiers can be soldered directly to the board by components, or using pre-assembled Adafruit modules soldered by connector points.
 If Adafruit modules aren't used then R14 and R15 aren't required, R13 should be 360K...390K

Title Audio			
Size: A4	Number:	Revision:1.0	
Date: 03.03.2018	Time: 11:47:32	Sheet 2 of 2	
File: C:\Work\DE10\Hardware_MiSTer\Addons\PiTopAudio\audio.SchDoc			



PiTopAudio v1.0 (C) 2018 Sorgelig

