



Notes:

- 1) Solder only U2a or U2b. Not both! Don't solder JP1.
- 2) If VBUS control is not required then solder JP1 and don't solder following components: U2, R12, R14, JP2. R13 can be 0.
- 3) Solder JP2 if over-current protection (~2.1A) is required.
- 4) uDFN6 version supports ~2.4A. TSOP6 ~1.2A (thermal shutdown)
- 4) JP3 to disable power control

Title 7-port USB Hub		
Size: A4	Number:	Revision: 2.1
Date: 04.07.2019	Time: 0:57:19	Sheet 1 of 1
File: C:\Work\MiSter\Hardware_MiSter\Addons\USBHub\USBHub.SchDoc		

Altium

MiSTer

..... FPGA

USB Hub v2.1 (c) 2019 Alexey Melnikov



