

6 String cable shorting method

1. Preparation. The cable must be soldered to the battery pack first, and then plugged into the protection board after checking it correctly. Do not plug the cables into the protection board and then solder them to the battery pack one by one
2. When wiring, connect B negative first, then connect the cable, and finally connect C negative to the negative pole of the charger and the load. The battery is always connected to the charger and battery
3. Start from the 4th series of cables on the board, connect the 4th to 19th series to the positive pole of the 4th battery of the battery pack, and the 20th series of cables to the 5th series of batteries. The positive pole of the battery, the 21st string is connected to the total the positive pole of the battery (that is, the 6th battery positive pole)

C negative to charge and discharge negative

