

Tablets

[illegible]

Pens

[illegible]

Mice

Category	Model Identifier	Weight	Size	Mouse Buttons	Button Travel	Scroll Wheel Type	Compatible Tablets
Mice	EC-155 [368]	90g	105 x 66.7 x 37.6 mm	3	???	Rotation, 24 steps per revolution	CTE-450, CTE-650
	EC-140 [369]	90g	106.2 x 62.3 x 37.4 mm	3	???	Rotation, 24 steps per revolution	CTE-440, CTE-640
	EC-130 [370]	90g	115 x 60 x 38 mm	3	???	Rotation, 24 steps per revolution	CTE-430, CTE-630BT, CTE-630
	EC-120 [371]	90g	116 x 58 x 37 mm	3	???	Rotation, 24 steps per revolution	ET-0405A-U, ET-0507A-U
	EC-100 [w/o weight] [90g [65g]		125 x 65 x 39 mm	3	???	Rotation, 24 steps per revolution	ET-0405-U, ET-0405-R
	KC-100 [w/o weight] [83g [58g]		102.9 x 61.8 x 38.6 mm	5	1.3mm	Rotation, 24 steps per revolution	PTK-440, PTK-540WL, PTK-640, PTK-840, PTK-1240
	KC-210 [374]	75g	159 x 66 x 33.8 mm	5	1.3mm	N/A	PTK-840, PTK-1240
	ZC-100 [w/o weight] [105g [70g]		112.0 x 58.0 x 38.0 mm	5	1mm	Rotation, 24 steps per revolution	PTZ-430, PTZ-431W, PTZ-630, PTZ-631W, PTZ-930, PTZ-1230, PTZ-1231W
	ZC-210 [376]	75g	159 x 66 x 33 mm	5	1mm	N/A	PTZ-1230, PTZ-1231W
	XC-100 [377]	100g	117.2 x 68.2 x 40.3 mm	3	1mm?	Rotation, 24 steps per revolution	XD-0405-U, XD-0405-R, XD-0608-U, XD-0608-R, XD-0912-U, XD-0912-R, XD-1212-U, XD-1212-R, XD-1218-U, XD-1218-R
	XC-400 [w/o weight] [105g [88g]		120.0 x 71.0 x 35.4 mm	5	1mm	Rotation, ???	XD-0405-U, XD-0405-R, XD-0608-U, XD-0608-R, XD-0912-U, XD-0912-R, XD-1212-U, XD-1212-R, XD-1218-U, XD-1218-R
	XC-210 [379]	75g	159 x 66 x 33 mm	5	1mm	N/A	XD-0405-U, XD-0405-R, XD-0608-U, XD-0608-R, XD-0912-U, XD-0912-R, XD-1212-U, XD-1212-R, XD-1218-U, XD-1218-R
	GC-500 [380]	75g	113 x 72.6 x 38.5 mm	5 + Thumbwheel	1mm	N/A	GD-0405-U, GD-0405-R, GD-0405-A, GD-0608-U, GD-0608-R, GD-0608-A, GD-0912-U, GD-0912-R, GD-0912-A, GD-1212-U, GD-1212-R, GD-1218-U, GD-1218-R
	GC-210 [381]	72g	158.9 x 66.1 x 33 mm	5	1mm	N/A	GD-0405-U, GD-0405-R, GD-0405-A, GD-0608-U, GD-0608-R, GD-0608-A, GD-0912-U, GD-0912-R, GD-0912-A, GD-1212-U, GD-1212-R, GD-1218-U, GD-1218-R
	UD-520 [382]	???	???	4	???	???	UD-0608-R, UD-0608-A, UD-1212-R, UD-1212-A, UD-1218-R, UD-1218-A, UD-0608-R, UD-0608-A, UD-1212-R, UD-1212-A, UD-1218-R, UD-1218-A, UD-1825-R
	UD-620 [383]	???	???	16	???	???	UD-1212-R, UD-1212-A, UD-1218-R, UD-1218-A, UD-1212-R, UD-1212-A, UD-1218-R, UD-1218-A, UD-1825-R
	SC-100 [384]	45g	55 x 118 x 21 mm	4	???	N/A	SD-420E, SD-421E, SD-422E, SD-320E, SD-321E, SD-322E, SD-310E, SD-311E, SD-312E, SD-210L
	SC-510 [385]	45g	55 x 118 x 21 mm	4	???	N/A	SD-510C
	SC-410 [386]	55g	62 x 130 x 24 mm	4	???	N/A	SD-013A, SD-013L
	SC-610 [387]	85g	62 x 130 x 24 mm	16	???	N/A	SD-013A, SD-013L

Kuuube's Info

Tablet Sheets and Guides

[Kuuube's Tablet Buying Guide](#)

[Kuuube's Wacom Tablet Mastersheet](#)

[Kuuube's Wacom Tablet Pen Compatibility Mastersheet](#)

[Kuuube's Wacom Pen Nib Guide](#)

[Kuuube's Wacom Pen Nib Compatibility Mastersheet](#)

Info

If you need to contact me personally, join my discord. I may not reply elsewhere.

[osu! Profile](#)

[Discord Server](#)

[Github](#)

[Youtube](#)

Sources

Not all sources are directly listed. Some information may be found in links or media contained in the pages below.

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq21ux-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq-software-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq20wsx-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq18sx-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq15x-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq12wx-usermanual-final.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-capture-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/intuos5-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-pen-bamboo-touch-bamboo-fun.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-fun-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos3-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire4-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire3-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos2-users-manual-win.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire2-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos-users-manual-mac.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos-users-manual-win.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphiremanual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphireusersmanual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire-bluetooth-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/penpartner-usb-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/penpartner.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dth2242-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dtk2241-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/dtu710-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dtf720-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/dtf521-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/intuosprosm1-2021updated/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos3-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacomintuos-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacom-intuos-2015-ipi/ipi-en.pdf>

<https://cdn.wacom.com/f/ipi/0x0302/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/onebywacom-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-capture-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/bamboo-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-pen-bamboo-touch-bamboo-fun.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-user-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-fun-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire4-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire3-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire-bluetooth-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire2-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphiremanual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacomintuospro-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos-pro-2017/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos5-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/intuos5-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos4-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/intuos4-wireless-users-manualkr.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/intuos4-users-manualkr.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wcp27/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wacomone-ipi-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/cintiq22-ipi-2021latest/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wacom-cintiq-pro-24-32ipi-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/cintiq-pro/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-computers/mobile-studio-pro/2020/ipi-en.pdf>

<https://cdn.wacom.com/f/ipi/0x0325/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x032B/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x032A/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x0304/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/cintiq-companion-warranty.pdf>

<https://cdn.wacom.com/f/ipi/0x005B/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00F8/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00FA/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00F4/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/pen-display-tablet-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq-software-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq12wx-usermanual-final.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq21ux-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq15x-user-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq18sx-user-manual.pdf>

<https://www.manualslib.com/manual/378157/Wacom-Sd-013a.html>

<https://www.manualslib.com/products/Wacom-Sd-210l-719853.html>

<https://www.manualslib.com/products/Wacom-Sd-310e-719843.html>

<https://www.manualslib.com/products/Wacom-Sd-311e-719844.html>

<https://www.manualslib.com/products/Wacom-Sd-312e-719851.html>

<https://www.manualslib.com/products/Wacom-Sd-320e-719845.html>

<https://www.manualslib.com/products/Wacom-Sd-321e-719846.html>

<https://www.manualslib.com/products/Wacom-Sd-322e-719847.html>

<https://www.manualslib.com/products/Wacom-Sd-420e-719848.html>

<https://www.manualslib.com/products/Wacom-Sd-421e-719849.html>

<https://www.manualslib.com/products/Wacom-Sd-422e-719850.html>

<https://www.manualslib.com/products/Wacom-Ctf-221-K-9366610.html>

<https://www.manualslib.com/products/Wacom-Cte-660-8828808.html>

<https://www.manualslib.com/products/Wacom-Cte-460-8828807.html>

<https://www.manualslib.com/products/Wacom-Ct-0405-U-9366374.html>

<https://www.manualslib.com/products/Wacom-Bamboo-Fun-Cth-461-12708124.html>

<https://www.manualslib.com/products/Wacom-Bamboo-Fun-Cth-661-12708125.html>

<https://fccid.io/HV4CTL4100WLA>

<https://fccid.io/HV4CTL6100WLA>

<https://fccid.io/HV4CTL6100WL>

<https://fccid.io/HV4CTL4100WL>

<https://fccid.io/HV4CTL6100>

<https://fccid.io/HV4CTL4100>

<https://fccid.io/HV4CTL672>

<https://fccid.io/HV4CTL472>

<https://fccid.io/HV4CTL671>

<https://fccid.io/HV4CTL471>

<https://fccid.io/HV4CTH690>

<https://fccid.io/HV4CTH490>

<https://fccid.io/HV4CTH301>

<https://fccid.io/HV4CTH300>

<https://fccid.io/HV4CTH680>

<https://fccid.io/HV4CTH480>

<https://fccid.io/HV4CTH670>

<https://fccid.io/HV4CTE660>

<https://fccid.io/HV4CTL-660>

<https://fccid.io/HV4CT0405U>

<https://fccid.io/HV4DTU1141BA>

<https://fccid.io/HV4DTC121>

<https://fccid.io/HV4DTH271>

<https://fccid.io/HV4DTH134>

<https://fccid.io/HV4DTH167>

<https://fccid.io/HV4DTC133>

<https://fccid.io/HV4DTHW1321>

<https://fccid.io/HV4DTU1031AX>

<https://fccid.io/HV4DTK2260>

<https://fccid.io/HV4DTHW1621>

<https://fccid.io/HV4DTK1660>
<https://fccid.io/HV4DTH2420>
<https://fccid.io/HV4DTH3220>
<https://fccid.io/HV4DTK2451>
<https://fccid.io/HV4DTH2452>
<https://fccid.io/HV4DTH1152>
<https://fccid.io/HV4DTU1141B>
<https://fccid.io/HV4DTH1620>
<https://fccid.io/HV4DTH1320>
<https://fccid.io/HV4DTHW1620>
<https://fccid.io/HV4DTHW1320>
<https://fccid.io/HV4DTK1651>
<https://fccid.io/HV4DTU1141>
<https://fccid.io/HV4DTK1301>
<https://fccid.io/HV4DTH1300>
<https://fccid.io/HV4DTK2700>
<https://fccid.io/HV4DTH2700>
<https://fccid.io/HV4DTHW1310>
<https://fccid.io/HV4DTU1031X>
<https://fccid.io/HV4DTU1031>
<https://fccid.io/HV4DTHW1300>
<https://fccid.io/HV4DTHA1300>
<https://fccid.io/HV4DTK2241>
<https://fccid.io/HV4DTH2242>
<https://fccid.io/HV4DTH2200>
<https://fccid.io/HV4DTK1300>
<https://fccid.io/HV4DTK2200>
<https://fccid.io/HV4DTH2400>
<https://fccid.io/HV4DTK2400>
<https://fccid.io/HV4DTU2235B>
<https://fccid.io/HV4DTF720C>
<https://fccid.io/HV4DTU1631>
<https://fccid.io/HV4DTK2100>
<https://fccid.io/HV4DTU2231A>
<https://fccid.io/HV4DTU2231>
<https://fccid.io/HV4DTF720A>
<https://fccid.io/HV4DTU1931>
<https://fccid.io/HV4DTZ2000W>
<https://fccid.io/HV4DTF521>
<https://fccid.io/HV4DTF720>
<https://fccid.io/HV4DTI520>
<https://fccid.io/HV4DTU710>
<https://fccid.io/HV4PTH460>
<https://fccid.io/HV4PTH860>
<https://fccid.io/HV4PTH660>
<https://fccid.io/HV4PTH851>
<https://fccid.io/HV4PTH651>
<https://fccid.io/HV4PTH451>
<https://fccid.io/HV4PTH850>
<https://fccid.io/HV4PTH650>
<https://fccid.io/HV4PTH450>
<https://fccid.io/HV4PTKW>
<https://fccid.io/HV4PTKL>
<https://fccid.io/HV4PTK>
<https://fccid.io/HV4PTZ>
<https://fccid.io/HV4PTZL>
<https://fccid.io/HV4PTU600>
<https://fccid.io/HV4PL700>
<https://fccid.io/HV4PL800>
<https://fccid.io/HV4PL550>
<https://fccid.io/HV4PL-500>
<https://fccid.io/HV4PL500>
<https://fccid.io/HV4PL400>

<https://fccid.io/HV4PL300>
<https://fccid.io/HV4PL100V1>
<https://fccid.io/HV4PL100V>
<https://fccid.io/HV4GD1212U>
<https://fccid.io/HV4GD0608U>
<https://fccid.io/HV4GD1218U>
<https://fccid.io/HV4GD0912U>
<https://fccid.io/HV4GD0405U>
<https://fccid.io/HV4GD0912A>
<https://fccid.io/HV4GD0405A>
<https://fccid.io/HV4GD0608A>
<https://fccid.io/HV4GD1212R>
<https://fccid.io/HV4GD1218R>
<https://fccid.io/HV4GD0912R>
<https://fccid.io/HV4GD0608R>
<https://fccid.io/HV4GD0405R>
<https://fccid.io/HV4FT0405U>
<https://fccid.io/HV4XD>
<https://fccid.io/HV4SD210L>
<https://fccid.io/HV4SD311E>
<https://fccid.io/HV4SD322E>
<https://fccid.io/HV4SD321E>
<https://fccid.io/HV4SD312E>
<https://fccid.io/HV4SD421E>
<https://fccid.io/HV4SD422E>
<https://fccid.io/HV4SD510C>
<https://fccid.io/HV4SD113L>
<https://fccid.io/HV4SD013L>
<https://fccid.io/HV4SD312L>
<https://fccid.io/HV4SD311L>
<https://fccid.io/HV4SD510B>
<https://fccid.io/HV4SD422A>
<https://fccid.io/HV4SD321A>
<https://fccid.io/HV4SD421A>
<https://fccid.io/HV4SD322A>
<https://fccid.io/HV4UD1825R>
<https://fccid.io/HV4UD1218RE>
<https://fccid.io/HV4UD1218R>
<https://fccid.io/HV4UD1212R>
<https://fccid.io/HV4UD0608R>
<https://fccid.io/HV4UD0608A>
<https://fccid.io/HV4UD1515R>
<https://fccid.io/HV4WKT400>
<https://fccid.io/HV4KT0405RNB23>
<https://fccid.io/HV4KT0405R>
<https://fccid.io/HV4KT0405A>
<http://lowtech-city.org/blog/index.php?e=189>
<http://lowtech-city.org/blog/index.php?e=188>
<http://lowtech-city.org/blog/index.php?e=187>
<http://lowtech-city.org/blog/index.php?e=186>
<http://lowtech-city.org/blog/index.php?e=185>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/ArtPad2.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/ArtPad2pro.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/UD2.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/prepio.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pl250.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pl300.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pens.html>
<https://web.archive.org/web/20010205040300/http://tablet.wacom.co.jp/products/ud/top.html>
<https://web.archive.org/web/20010205021100/http://tablet.wacom.co.jp/products/artpadfun/top.html>
https://web.archive.org/web/20001215051200/http://tablet.wacom.co.jp/products/pl/pl_index.html
<https://web.archive.org/web/20010409192903/http://tablet.wacom.co.jp/products/favo/open.html>
https://web.archive.org/web/20010204061900/http://tablet.wacom.co.jp/products/intuos/intuos_index.html

https://web.archive.org/web/20031003002009/http://tablet.wacom.co.jp/products/intuos2/hardware_top.html

<https://web.archive.org/web/20031001235545/http://tablet.wacom.co.jp/products/cintiq/index.html>

<https://web.archive.org/web/20030807113820/http://tablet.wacom.co.jp/products/favo2/index.html>

- [1] (Wacom One S)
- [2] Wacom One Standard Pen
- [3] (Wacom One M)
- [4] Wacom One Standard Pen
- [5] (Intuos S) (Wacom Intuos, Pen Only Small)
- [6] (Wacom Pen 4K)
- [7] (Intuos BT S) (Wacom Intuos, Pen & Bluetooth Small)
- [8] (Wacom Pen 4K)
- [9] (Intuos M) (Wacom Intuos, Pen Only Medium)
- [10] (Wacom Pen 4K)
- [11] (Intuos BT M) (Wacom Intuos, Pen & Bluetooth Medium)
- [12] (Wacom Pen 4K)
- [13] (Intuos Draw Small) (Intuos Small)
- [14] (Wacom Pen 2K)
- [15] (Intuos Art Small) (Intuos Photo Small) (Intuos Comic Small) (Intuos Touch Small)
- [16] (Wacom Pen 2K)
- [17] (Intuos Draw Medium) (Intuos Medium)
- [18] (Wacom Pen 2K)
- [19] (Intuos Art Medium) (Intuos Touch Medium)
- [20] (Wacom Pen 2K)
- [21] (Intuos Pen (S)) (Intuos Small) (Intuos Creative Pen Tablet - Small)
- [22] (Intuos Pen & Touch (S)) (Intuos Touch Small) (Intuos Creative Pen & Touch Tablet - Small)
- [23] (Intuos Pen & Touch (M)) (Intuos Medium)
- [24] (Intuos Pen (M)) (Intuos Touch Medium) (Intuos Creative Pen & Touch Tablet - Medium)
- [25] (One by Wacom (S)) (One by Wacom small) (One by Wacom pen tablet)
- [26] (Wacom Pen 2K)
- [27] (One by Wacom (M)) (One by Wacom medium) (One by Wacom pen tablet)
- [28] (Wacom Pen 2K)
- [29] (Bamboo Splash) (One by Wacom (S))

[30] (One by Wacom (M))

[31] (Bamboo Connect) (Bamboo Pen Tablet)

[32] (Bamboo Capture) (Bamboo Manga) (Bamboo Comic)

[33] (Bamboo Create) (Bamboo Fun) (Bamboo Comic)

[34] (Bamboo One Pen (S)) (Bamboo One, Small Tablet)

[35] (Bamboo One Pen)

[36] (Bamboo One Pen (M)) (Bamboo One, Medium Tablet)

[37] (Bamboo One Pen)

[38] (Bamboo Fun (S)) (Bamboo Craft (S)) (Bamboo Comic Pen & Touch (S)) (Bamboo Pen & Touch Special Edition (S)) (Bamboo Fun Small Tablet) (Bamboo Fun Pen & Touch) (Bamboo Comic Pen & Touch) (Bamboo Tablet)

[39] (Bamboo Fun CTH Pen)

[40] (Bamboo Fun (M)) (Bamboo Comic Pen & Touch (M)) (Bamboo Pen & Touch Special Edition (M)) (Bamboo Fun Medium Tablet) (Bamboo Tablet)

[41] (Bamboo Fun CTH Pen)

[42] (Bamboo Pen (S)) (Bamboo Pen Tablet)

[43] (Bamboo CTL Pen)

[44] (Bamboo Pen & Touch) (Bamboo Pen & Touch) (Bamboo Tablet)

[45] (Bamboo CTH Pen)

[46] (Bamboo Touch) (Bamboo Touch Tablet) [no emr digitizer]

[47] (Bamboo Pen (M)) (Bamboo Pen Tablet)

[48] (Bamboo) (Bamboo Tablet)

[49] (Bamboo Pen)

[50] (Bamboo Fun (4x5)) (Small Bamboo Fun Tablet)

[51] (Bamboo Fun Pen)

[52] (Bamboo Fun (6x8)) (Medium Bamboo Fun Tablet)

[53] (Bamboo Fun Pen)

[54] (Wacom FAVO Wireless FW-300USB)

[55] (Graphire4 (4x5))

[56] (Graphire4 Pen)

[57] (Graphire4 (6x8))

[58] (Graphire4 Pen)

[59] (Bamboo Pad USB model, Bamboo Pad Light)

[60] (Bamboo Pad wireless model)

[61] (Graphire3 Pen)

[62] (Graphire3 (4x5)) (Graphire3 4x5 / A6 Tablet) (F-430)

[63] (Graphire3 Pen)

[64] (Graphire Bluetooth Pen Tablet)

[65] (Graphire Pen)

[66] (Graphire3 (6x8)) (Graphire3 6x8 / A5 Tablet) (F-630)

[67] (Graphire3 Pen)

[68] (Bamboo One) (Bamboo One Tablet)

[69] (PenPartner2)

[70] (Volito 2 A6)

[71] (Volito) (PenPartner) (PenStation (2x3))

[72] (Volito) (PenPartner) (PenStation (4x5)) (LLC Tablet)

[73] (LLC Pen)

[74] (Graphire2 (4x5)) (Graphire2 Tablet) (Graphire2 USB Tablet) (F-410)

[75] (Graphire2 Pen)

[76] (Graphire2 (5x7)) (F-510)

[77] (Graphire) (Graphire Tablet) (F-401U) (Wacom FAVO USB)

[78] (Graphire Pen)

[79] (Graphire) (Graphire Tablet)

[80] (Graphire Pen)

[81] (ARTPAD FAN) (PenParter Tablet)

[82] (PenPartner Pen) (UltraPen)

[83] (ARTPAD FAN) (PenParter Tablet)

[84] (PenPartner Pen) (UltraPen)

[85] (ARTPAD FAN) (PenParter Tablet)

[86] (PenPartner Pen) (UltraPen)

[87] (ART Z)

[88] (UltraPen Eraser) (Erasing UltraPen)

[89] (ART Z II)

[90] (UltraPen Eraser) (Erasing UltraPen)

[91] (ARTPAD II Serial) (ArtPad II A6 Serial)

[92] (UltraPen Eraser) (Erasing UltraPen)

[93] (ARTPAD II ADB) (ArtPad II A6 ADB)

[94] (UltraPen Eraser) (Erasing UltraPen)

[95] (ARTPAD)

[96] (UltraPen Eraser) (Erasing UltraPen)

[97] (ARTPAD)

[98] (UltraPen Eraser) (Erasing UltraPen)

[99] (Intuos Pro 2025 Small)

[100] (Intuos Pro 2025 Medium)

[101] (Intuos Pro 2025 Large)

[102] (Intuos Pro Small) (Wacom Intuos Pro)

[103] (Wacom Pro Pen 2)

[104] (Intuos Pro Medium) (Wacom Intuos Pro)

[105] (Wacom Pro Pen 2)

[106] (Intuos Pro Large) (Wacom Intuos Pro)

[107] (Wacom Pro Pen 2)

[108] (Intuos pro (S)) (Intuos Pro Professional Pen & Touch Tablet - Small) (Intuos Pro Touch S Tablet)
(Intuos Pro Small)

[109] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[110] (Intuos pro (M)) (Intuos Pro Professional Pen & Touch Tablet - Medium) (Intuos Pro Touch M Tablet)
(Intuos Pro Medium) (Intuos Pro Medium Special Edition)

[111] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[112] (Intuos pro (L)) (Intuos Pro Professional Pen & Touch Tablet - Large) (Intuos Pro Touch L Tablet)
(Intuos Pro Large)

[113] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[114] (Intuos5 touch (S)) (Wacom Intuos5 Touch (Small))

[115] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[116] (Intuos5 (S)) (Wacom Intuos5 (Small))

[117] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[118] (Intuos5 touch (M)) (Wacom Intuos5 Touch (Medium))

[119] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[120] (Intuos5 (M)) (Wacom Intuos5 (Medium))

[121] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[122] (Intuos5 touch (L)) (Wacom Intuos5 Touch (Large))

[123] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[124] (Intuos4 (4x6)) (Intuos4 S Tablet) (Intuos4 Small) (Intuos4 Special Edition) (Intuos 4 Comic Edition)

[125] (Intuos4 Grip Pen)

[126] (Intuos4 Wireless) (Intuos4 Wireless Tablet)

[127] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[128] (Intuos4 (6x9)) (Intuos4 M Tablet) (Intuos4 Medium) (Intuos4 Special Edition) (Intuos 4 Comic Edition)

[129] (Intuos4 Grip Pen)

[130] (Intuos4 (8x13)) (Intuos4 L Tablet) (Intuos4 Large)

[131] (Intuos4 Grip Pen)

[132] (Intuos4 (12x19)) (Intuos4 XL Tablet) (Intuos4 Extra Large)

[133] (Intuos4 Grip Pen)

[134] (Intuos3 (4x5)) (Intuos3 4x5 / A6 Tablet)

[135] (Intuos3 Grip Pen)

[136] (Intuos3 (4x6)) (Intuos3 4x6 / A6 Wide Tablet)

[137] (Intuos3 Grip Pen)

[138] (Intuos3 (6x8)) (Intuos3 6x8 / A5 Tablet)

[139] (Intuos3 Grip Pen)

[140] (Intuos3 (6x11)) (Intuos3 6x11 / A5 Wide Tablet)

[141] (Intuos3 Grip Pen)

[142] (Intuos3 (9x12)) (Intuos3 9x12 / A4-Regular Tablet)

[143] (Intuos3 Grip Pen)

[144] (Intuos3 (12x12)) (Intuos3 12x12 / A4 Oversize Tablet)

[145] (Intuos3 Grip Pen)

[146] (Intuos3 (12x19)) (Intuos3 12x19 / A3 Wide Tablet)

[147] (Intuos3 Grip Pen)

[148] Cintiq Partner

[149] (Intuos2 (4x5)) (Intuos2 4x5 / A6 Tablet) (I-420USB)

[150] (Intuos2 Grip Pen)

[151] (Intuos2 (4x5)) (Intuos2 4x5 / A6 Tablet) (I-420Serial)

[152] (Intuos2 Grip Pen)

[153] (Intuos2 (6x8)) (Intuos2 6x8 / A5 Tablet) (I-620USB)

[154] (Intuos2 Grip Pen)

[155] (Intuos2 (6x8)) (Intuos2 6x8 / A5 Tablet) (I-620Serial)

[156] (Intuos2 Grip Pen)

[157] (Intuos2 (9x12)) (Intuos2 9x12 / A4-Regular Tablet) (I-920USB)

[158] (Intuos2 Grip Pen)

[159] (Intuos2 (9x12)) (Intuos2 9x12 / A4-Regular Tablet) (I-920Serial)

[160] (Intuos2 Grip Pen)

[161] (Intuos2 (12x12)) (Intuos2 12x12 / A4-Oversize Tablet) (I-1220USB)

[162] (Intuos2 Grip Pen)

[163] (Intuos2 (12x12)) (Intuos2 12x12 / A4-Oversize Tablet) (I-1220Serial)

[164] (Intuos2 Grip Pen)

[165] (Intuos2 (12x18)) (Intuos2 12x18 / A3 Tablet) (I-1820USB)

[166] (Intuos2 Grip Pen)

[167] (Intuos2 (12x18)) (Intuos2 12x18 / A3 Tablet) (I-1820Serial)

[168] (Intuos2 Grip Pen)

[169] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400USB)

[170] (Intuos Pen)

[171] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400Serial)

[172] (Intuos Pen)

[173] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400ADB)

[174] (Intuos Pen)

[175] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600USB)

[176] (Intuos Pen)

[177] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600Serial)

[178] (Intuos Pen)

[179] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600ADB)

[180] (Intuos Pen)

[181] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900USB)

[182] (Intuos Pen)

[183] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900Serial)

[184] (Intuos Pen)

[185] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900ADB)

[186] (Intuos Pen)

[187] (Intuos (12x12)) (Intuos 12x12 Tablet) (I-1200USB)

[188] (Intuos Pen)

[189] (Intuos (12x12)) (Intuos 12x12 Tablet) (I-1200Serial)

[190] (Intuos Pen)

[191] (Intuos (12x18)) (Intuos 12x18 Tablet) (I-1800USB)

[192] (Intuos Pen)

[193] (Intuos (12x18)) (Intuos 12x18 Tablet) (I-1800Serial)

[194] (Intuos Pen)

[195] (ART Z II)

[196] (UltraPen Eraser) (Erasing UltraPen)

[197] (ART Z II)

[198] (UltraPen Eraser) (Erasing UltraPen)

[199] (ART Z II)

[200] (UltraPen Eraser) (Erasing UltraPen)

[201] (ART Z II)

[202] (UltraPen Eraser) (Erasing UltraPen)

[203] (ART Z II)

[204] (UltraPen Eraser) (Erasing UltraPen)

[205] (ART Z II)

[206] (UltraPen Eraser) (Erasing UltraPen)

[207] (Artpad II Pro Serial) (UltraPad A5 Serial)

[208] (UltraPen Eraser) (Erasing UltraPen)

[209] (Artpad II Pro ADB) (UltraPad A5 ADB)

[210] (UltraPen Eraser) (Erasing UltraPen)

[211] (UD-1212 II) (ULTRAPAD II) (UltraPad A4) (UD-1212-RSR) (UD-1212-RSB)

[212] (UltraPen Eraser) (Erasing UltraPen)

[213] (UD-1218 II / E) (UD-1218 II / S) (ULTRAPAD II) (UltraPad A3) (UD-1218-RER) (UD-1218-RSR)

[214] (UltraPen Eraser) (Erasing UltraPen)

[215] (UD-1825 II) (ULTRAPAD II) (UltraPad A2) (UD-1825-RSR)

[216] (UltraPen Eraser) (Erasing UltraPen)

[217] (Standard 6 x 9)

[218] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[219] (Standard 12 x 12)

[220] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[221] (Electrostatic 12 x 12)

[222] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[223] (Menu Panel 12 x 12)

[224] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[225] (Standard 15 x 15)

[226] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[227] (Electrostatic 15 x 15)

[228] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[229] (Menu Panel 15 x 15)

[230] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[231] (Standard 12 x 18)

[232] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[233] (Electrostatic 12 x 18)

[234] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[235] (Menu Panel 12 x 18)

[236] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[237] (Standard 18 x 25)

[238] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[239] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[240] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[241] (Wacom One Standard Pen)

[242] (Wacom One Pen)

[243] (Dr. Grip Digital for Wacom ブラック) (Dr. Grip Digital for Wacom アクアブルー)

[244] (LAMY AL-Star black EMR Pen)

[245] (STAEDTLER Noris digital classic Stylus)

[246] (STAEDTLER Noris digital jumbo Stylus)

[247] (Wacom Pen 4K)

[248] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[249] (Wacom Pen 2K)

[250] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[251] (Wacom Pen 2K)

[252] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[253] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[254] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[255] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[256] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[257] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[258] (Bamboo Fun CTH Pen)

[259] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[260] (Bamboo CTL Pen)

[261] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[262] (Bamboo CTH Pen)

[263] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[264] (Bamboo One Pen)

[265] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[266] (Bamboo Pen)

[267] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[268] (Bamboo Fun Pen)

[269] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[270] (Graphire4 Pen)

[271] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[272] (Bamboo One Pen)

[273] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[274] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[275] (Graphire3 Inking Pen) (Graphire2 Inking Pen) (Graphire Inking Pen)

[276] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[277] (Graphire Pen)

[278] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[279] (Graphire3 Pen)

[280] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[281] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[282] (LLC Pen)

[283] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[284] (Graphire2 Pen)

[285] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[286] (Graphire Pen)

[287] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[288] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[289] (PenPartner Pen) (UltraPen)

[290] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[291] (Wacom Pro Pen 3)

[292] (Wacom Pro Pen 2)

[293] (Wacom Pro Pen Slim)

[294] (Wacom Pro Pen 3d)

[295] (Wacom Finetip Pen)

[296] (PSI-A024-BK, PSI-A025-R, PSI-A026-BL, PSI-A024-BK-01, PSI-A011, PSI-A023, FUZ-A010-03)

[297] (Wacom Ballpoint Pen)

[298] (PSI-A024-BK, PSI-A025-R, PSI-A026-BL, PSI-A024-BK-01, PSI-A011, PSI-A023, FUZ-A010-03)

[299] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[300] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[301] (Intuos4 Grip Pen)

[302] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[303] (Wacom Pro Pen)

[304] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[305] (Intuos4 Airbrush) (Intuos5 Airbrush) (Wacom Airbrush)

[306] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[307] (Intuos4 Inking Pen) (Intuos5 Inking Pen) (Wacom Inking Pen)

[308] (PSI-A024-BK, PSI-A025-R, PSI-A026-BL, PSI-A024-BK-01, PSI-A011, PSI-A023, FUZ-A010-03)

[309] (Intuos4 Art Pen) (Intuos5 Art Pen) (Wacom Art Pen)

[310] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[311] (Intuos4 Classic Pen) (Intuos5 Classic Pen) (Wacom Classic Pen)

[312] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[313] (Intuos3 Grip Pen)

[314] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[315] (Intuos3 Airbrush)

[316] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[317] (Intuos3 Art Pen)

[318] (Intuos3 Ink Pen)

[319] (PSI-A024-BK, PSI-A025-R, PSI-A026-BL, PSI-A024-BK-01, PSI-A011, PSI-A023, FUZ-A010-03)

[320] (Intuos3 Classic Pen)

[321] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[322] (Intuos2 Grip Pen)

[323] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[324] (Intuos2 Airbrush)

[325] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[326] (Intuos2 Classic Pen)

[327] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[328] (Intuos2 Ink Pen)

[329] (PSI-A024-BK, PSI-A025-R, PSI-A026-BL, PSI-A024-BK-01, PSI-A011, PSI-A023, FUZ-A010-03)

[330] (Intuos2 Stroke Pen)

[331] (PSI-A024-BK, PSI-A025-R, PSI-A026-BL, PSI-A024-BK-01, PSI-A011, PSI-A023, FUZ-A010-03)

[332] (Intuos Pen)

[333] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[334] (Intuos Airbrush)

[335] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[336] (Intuos Inking Pen)

[337] (PSI-A024-BK, PSI-A025-R, PSI-A026-BL, PSI-A024-BK-01, PSI-A011, PSI-A023, FUZ-A010-03)

[338] (Intuos Stroke Pen)

[339] (PSI-A024-BK, PSI-A025-R, PSI-A026-BL, PSI-A024-BK-01, PSI-A011, PSI-A023, FUZ-A010-03)

[340] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[341] (UltraPen Eraser) (Erasing UltraPen)

[342] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[343] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[344] Click pen

[345] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[346] (UltraPen Brush)

[347] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[348] (UltraPen Pencil)

[349] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[350] (Grip Pen)

[351] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[352] (Grip Pen)

[353] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[354] (UltraPen 813E)

[355] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[356] (UltraPen Write)

[357] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[358] (UltraPen Write)

[359] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[360] (UltraPen Ink)

[361] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A021)

[362] (Standard Stylus Gray)

[363] (Standard Stylus Red)

[364] (Slim Stylus Gray)

[365] (Slim Stylus Magenta)

[366] (Pressure Stylus Blue)

[367] (Pressure Stylus Red)

[368] BAMBOO FUN CORDLESS MOUSE

[369] Graphire4 cordless mouse

[370] GRAPHIRE3 CORDLESS MOUSE

[371] GRAPHIRE2 CORDLESS MOUSE

[372] GRAPHIRE CORDLESS MOUSE

[373] INTUOS4 MOUSE

[374] INTUOS4 LENS CURSOR

[375] Intuos3 mouse

[376] Intuos3 lens cursor

[377] INTUOS2 2D MOUSE

[378] INTUOS2 4D MOUSE

[379] INTUOS2 LENS CURSOR

[380] INTUOS 4D MOUSE

[381] INTUOS LENS CURSOR

[382] 4-button cursor

[383] 16 button cursor

[384] Four-Button Cursor

[385] Four-Button Cursor

[386] Four-Button Cursor

[387] Sixteen-Button Cursor