

Kuuube's Wacom Tablet Mastersheet

Tablets										Pens										Mice									
Tablets										Pens										Mice									
Model	Release Date	Size (mm)	Resolution (DPI)	Pressure Sensitivity (Levels)	Active Area (mm)	Weight (g)	Material	Connectivity	Price (USD)	Model	Release Date	Size (mm)	Resolution (DPI)	Pressure Sensitivity (Levels)	Active Area (mm)	Weight (g)	Material	Connectivity	Price (USD)	Model	Release Date	Size (mm)	Resolution (DPI)	Pressure Sensitivity (Levels)	Active Area (mm)	Weight (g)	Material	Connectivity	Price (USD)
Intuos3 610	2006	305 x 183	5064	1024	254 x 152	100	Plastic	USB	150	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 610	2006	305 x 183	5064	1024	254 x 152	100	Plastic	USB	150
Intuos3 920	2006	354 x 218	5064	1024	292 x 178	120	Plastic	USB	200	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 920	2006	354 x 218	5064	1024	292 x 178	120	Plastic	USB	200
Intuos3 1220	2006	406 x 244	5064	1024	344 x 200	140	Plastic	USB	250	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 1220	2006	406 x 244	5064	1024	344 x 200	140	Plastic	USB	250
Intuos3 1520	2006	457 x 274	5064	1024	395 x 230	160	Plastic	USB	300	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 1520	2006	457 x 274	5064	1024	395 x 230	160	Plastic	USB	300
Intuos3 2160	2006	594 x 354	5064	1024	510 x 298	200	Plastic	USB	400	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 2160	2006	594 x 354	5064	1024	510 x 298	200	Plastic	USB	400
Intuos3 2460	2006	635 x 384	5064	1024	551 x 328	220	Plastic	USB	450	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 2460	2006	635 x 384	5064	1024	551 x 328	220	Plastic	USB	450
Intuos3 3160	2006	762 x 457	5064	1024	678 x 401	260	Plastic	USB	550	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 3160	2006	762 x 457	5064	1024	678 x 401	260	Plastic	USB	550
Intuos3 4460	2006	1016 x 609	5064	1024	914 x 544	320	Plastic	USB	700	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 4460	2006	1016 x 609	5064	1024	914 x 544	320	Plastic	USB	700
Intuos3 6160	2006	1270 x 762	5064	1024	1168 x 707	380	Plastic	USB	850	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 6160	2006	1270 x 762	5064	1024	1168 x 707	380	Plastic	USB	850
Intuos3 8460	2006	1524 x 914	5064	1024	1414 x 851	440	Plastic	USB	1000	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 8460	2006	1524 x 914	5064	1024	1414 x 851	440	Plastic	USB	1000
Intuos3 12160	2006	2032 x 1219	5064	1024	1914 x 1145	500	Plastic	USB	1200	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 12160	2006	2032 x 1219	5064	1024	1914 x 1145	500	Plastic	USB	1200
Intuos3 15160	2006	2286 x 1397	5064	1024	2168 x 1323	560	Plastic	USB	1350	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 15160	2006	2286 x 1397	5064	1024	2168 x 1323	560	Plastic	USB	1350
Intuos3 22160	2006	2794 x 1678	5064	1024	2676 x 1601	620	Plastic	USB	1500	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 22160	2006	2794 x 1678	5064	1024	2676 x 1601	620	Plastic	USB	1500
Intuos3 31160	2006	3542 x 2152	5064	1024	3424 x 2073	680	Plastic	USB	1700	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 31160	2006	3542 x 2152	5064	1024	3424 x 2073	680	Plastic	USB	1700
Intuos3 44160	2006	4570 x 2794	5064	1024	4462 x 2751	740	Plastic	USB	1900	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 44160	2006	4570 x 2794	5064	1024	4462 x 2751	740	Plastic	USB	1900
Intuos3 61160	2006	5942 x 3542	5064	1024	5834 x 3509	800	Plastic	USB	2100	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 61160	2006	5942 x 3542	5064	1024	5834 x 3509	800	Plastic	USB	2100
Intuos3 84160	2006	7620 x 4570	5064	1024	7512 x 4427	860	Plastic	USB	2300	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 84160	2006	7620 x 4570	5064	1024	7512 x 4427	860	Plastic	USB	2300
Intuos3 121160	2006	10160 x 6092	5064	1024	10042 x 5945	920	Plastic	USB	2500	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 121160	2006	10160 x 6092	5064	1024	10042 x 5945	920	Plastic	USB	2500
Intuos3 151160	2006	12700 x 7620	5064	1024	12582 x 7513	980	Plastic	USB	2700	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 151160	2006	12700 x 7620	5064	1024	12582 x 7513	980	Plastic	USB	2700
Intuos3 221160	2006	17820 x 10414	5064	1024	17702 x 10285	1040	Plastic	USB	3000	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 221160	2006	17820 x 10414	5064	1024	17702 x 10285	1040	Plastic	USB	3000
Intuos3 311160	2006	22900 x 13970	5064	1024	22782 x 13847	1100	Plastic	USB	3300	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 311160	2006	22900 x 13970	5064	1024	22782 x 13847	1100	Plastic	USB	3300
Intuos3 441160	2006	29820 x 18146	5064	1024	29702 x 18019	1160	Plastic	USB	3600	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 441160	2006	29820 x 18146	5064	1024	29702 x 18019	1160	Plastic	USB	3600
Intuos3 611160	2006	37820 x 22860	5064	1024	37702 x 22731	1220	Plastic	USB	3900	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 611160	2006	37820 x 22860	5064	1024	37702 x 22731	1220	Plastic	USB	3900
Intuos3 841160	2006	47820 x 29146	5064	1024	47702 x 29019	1280	Plastic	USB	4200	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 841160	2006	47820 x 29146	5064	1024	47702 x 29019	1280	Plastic	USB	4200
Intuos3 1211160	2006	61820 x 37146	5064	1024	61702 x 36919	1340	Plastic	USB	4500	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 1211160	2006	61820 x 37146	5064	1024	61702 x 36919	1340	Plastic	USB	4500
Intuos3 1511160	2006	77820 x 46146	5064	1024	77702 x 45919	1400	Plastic	USB	4800	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 1511160	2006	77820 x 46146	5064	1024	77702 x 45919	1400	Plastic	USB	4800
Intuos3 2211160	2006	101820 x 59146	5064	1024	101702 x 59019	1460	Plastic	USB	5100	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 2211160	2006	101820 x 59146	5064	1024	101702 x 59019	1460	Plastic	USB	5100
Intuos3 3111160	2006	127820 x 76146	5064	1024	127702 x 75919	1520	Plastic	USB	5400	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 3111160	2006	127820 x 76146	5064	1024	127702 x 75919	1520	Plastic	USB	5400
Intuos3 4411160	2006	167820 x 101146	5064	1024	167702 x 100919	1580	Plastic	USB	5700	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 4411160	2006	167820 x 101146	5064	1024	167702 x 100919	1580	Plastic	USB	5700
Intuos3 6111160	2006	217820 x 129146	5064	1024	217702 x 128919	1640	Plastic	USB	6000	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 6111160	2006	217820 x 129146	5064	1024	217702 x 128919	1640	Plastic	USB	6000
Intuos3 8411160	2006	277820 x 166146	5064	1024	277702 x 165919	1700	Plastic	USB	6300	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 8411160	2006	277820 x 166146	5064	1024	277702 x 165919	1700	Plastic	USB	6300
Intuos3 12111160	2006	357820 x 211146	5064	1024	357702 x 210919	1760	Plastic	USB	6600	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 12111160	2006	357820 x 211146	5064	1024	357702 x 210919	1760	Plastic	USB	6600
Intuos3 15111160	2006	457820 x 269146	5064	1024	457702 x 268919	1820	Plastic	USB	6900	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 15111160	2006	457820 x 269146	5064	1024	457702 x 268919	1820	Plastic	USB	6900
Intuos3 22111160	2006	597820 x 349146	5064	1024	597702 x 348919	1880	Plastic	USB	7200	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 22111160	2006	597820 x 349146	5064	1024	597702 x 348919	1880	Plastic	USB	7200
Intuos3 31111160	2006	777820 x 469146	5064	1024	777702 x 468919	1940	Plastic	USB	7500	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 31111160	2006	777820 x 469146	5064	1024	777702 x 468919	1940	Plastic	USB	7500
Intuos3 44111160	2006	977820 x 599146	5064	1024	977702 x 598919	2000	Plastic	USB	7800	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 44111160	2006	977820 x 599146	5064	1024	977702 x 598919	2000	Plastic	USB	7800
Intuos3 61111160	2006	1277820 x 769146	5064	1024	1277702 x 768919	2060	Plastic	USB	8100	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 61111160	2006	1277820 x 769146	5064	1024	1277702 x 768919	2060	Plastic	USB	8100
Intuos3 84111160	2006	1677820 x 1019146	5064	1024	1677702 x 1018919	2120	Plastic	USB	8400	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 84111160	2006	1677820 x 1019146	5064	1024	1677702 x 1018919	2120	Plastic	USB	8400
Intuos3 121111160	2006	2177820 x 129146	5064	1024	2177702 x 128919	2180	Plastic	USB	8700	Pro Pen 2	2009	127 x 91	5064	1024	254 x 152	100	Plastic	USB	150	Intuos3 1									

Kuuube's Info

Tablet Sheets and Guides

[Kuuube's Tablet Buying Guide](#)

[Kuuube's Wacom Tablet Mastersheet](#)

[Kuuube's Wacom Tablet Pen Compatibility Mastersheet](#)

[Kuuube's Wacom Pen Nib Guide](#)

Info

If you need to contact me personally, join my discord. I may not reply elsewhere.

[osu! Profile](#)

[Discord Server](#)

[Github](#)

[Youtube](#)

Sources

Not all sources are directly listed. Some information may be found in links or media contained in the pages below.

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq21ux-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq-software-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq20wsx-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq18sx-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq15x-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq12wx-usermanual-final.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-capture-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/intuos5-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-pen-bamboo-touch-bamboo-fun.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-fun-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos3-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire4-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire3-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos2-users-manual-win.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire2-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos-users-manual-mac.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos-users-manual-win.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphiremanual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphireusersmanual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire-bluetooth-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/penpartner-usb-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/penpartner.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dth2242-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dtk2241-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/dtu710-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dtf720-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/dtf521-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/intuosprosm1-2021updated/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos3-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacomintuos-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacom-intuos-2015-ipi/ipi-en.pdf>

<https://cdn.wacom.com/f/ipi/0x0302/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/onebywacom-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-capture-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/bamboo-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-pen-bamboo-touch-bamboo-fun.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-user-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-fun-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire4-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire3-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire-bluetooth-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire2-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphiremanual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacomintuospro-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos-pro-2017/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos5-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/intuos5-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos4-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/intuos4-wireless-users-manualkr.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/intuos4-users-manualkr.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wcp27/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wacomone-ipi-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/cintiq22-ipi-2021latest/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wacom-cintiq-pro-24-32ipi-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/cintiq-pro/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-computers/mobile-studio-pro/2020/ipi-en.pdf>

<https://cdn.wacom.com/f/ipi/0x0325/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x032B/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x032A/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x0304/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/cintiq-companion-warranty.pdf>

<https://cdn.wacom.com/f/ipi/0x005B/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00F8/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00FA/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00F4/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/pen-display-tablet-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq-software-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq12wx-usermanual-final.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq21ux-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq15x-user-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq18sx-user-manual.pdf>

<https://www.manualslib.com/manual/378157/Wacom-Sd-013a.html>

<https://www.manualslib.com/products/Wacom-Sd-210l-719853.html>

<https://www.manualslib.com/products/Wacom-Sd-310e-719843.html>

<https://www.manualslib.com/products/Wacom-Sd-311e-719844.html>

<https://www.manualslib.com/products/Wacom-Sd-312e-719851.html>

<https://www.manualslib.com/products/Wacom-Sd-320e-719845.html>

<https://www.manualslib.com/products/Wacom-Sd-321e-719846.html>

<https://www.manualslib.com/products/Wacom-Sd-322e-719847.html>

<https://www.manualslib.com/products/Wacom-Sd-420e-719848.html>

<https://www.manualslib.com/products/Wacom-Sd-421e-719849.html>

<https://www.manualslib.com/products/Wacom-Sd-422e-719850.html>

<https://www.manualslib.com/products/Wacom-Ctf-221-K-9366610.html>

<https://www.manualslib.com/products/Wacom-Cte-660-8828808.html>

<https://www.manualslib.com/products/Wacom-Cte-460-8828807.html>

<https://www.manualslib.com/products/Wacom-Ct-0405-U-9366374.html>

<https://www.manualslib.com/products/Wacom-Bamboo-Fun-Cth-461-12708124.html>

<https://www.manualslib.com/products/Wacom-Bamboo-Fun-Cth-661-12708125.html>

<https://fccid.io/HV4CTL4100WLA>

<https://fccid.io/HV4CTL6100WLA>

<https://fccid.io/HV4CTL6100WL>

<https://fccid.io/HV4CTL4100WL>

<https://fccid.io/HV4CTL6100>

<https://fccid.io/HV4CTL4100>

<https://fccid.io/HV4CTL672>

<https://fccid.io/HV4CTL472>

<https://fccid.io/HV4CTL671>

<https://fccid.io/HV4CTL471>

<https://fccid.io/HV4CTH690>

<https://fccid.io/HV4CTH490>

<https://fccid.io/HV4CTH301>

<https://fccid.io/HV4CTH300>

<https://fccid.io/HV4CTH680>

<https://fccid.io/HV4CTH480>

<https://fccid.io/HV4CTH670>

<https://fccid.io/HV4CTE660>

<https://fccid.io/HV4CTL-660>

<https://fccid.io/HV4CT0405U>

<https://fccid.io/HV4DTU1141BA>

<https://fccid.io/HV4DTC121>

<https://fccid.io/HV4DTH271>

<https://fccid.io/HV4DTH134>

<https://fccid.io/HV4DTH167>

<https://fccid.io/HV4DTC133>

<https://fccid.io/HV4DTHW1321>

<https://fccid.io/HV4DTU1031AX>

<https://fccid.io/HV4DTK2260>

<https://fccid.io/HV4DTHW1621>

<https://fccid.io/HV4DTK1660>
<https://fccid.io/HV4DTH2420>
<https://fccid.io/HV4DTH3220>
<https://fccid.io/HV4DTK2451>
<https://fccid.io/HV4DTH2452>
<https://fccid.io/HV4DTH1152>
<https://fccid.io/HV4DTU1141B>
<https://fccid.io/HV4DTH1620>
<https://fccid.io/HV4DTH1320>
<https://fccid.io/HV4DTHW1620>
<https://fccid.io/HV4DTHW1320>
<https://fccid.io/HV4DTK1651>
<https://fccid.io/HV4DTU1141>
<https://fccid.io/HV4DTK1301>
<https://fccid.io/HV4DTH1300>
<https://fccid.io/HV4DTK2700>
<https://fccid.io/HV4DTH2700>
<https://fccid.io/HV4DTHW1310>
<https://fccid.io/HV4DTU1031X>
<https://fccid.io/HV4DTU1031>
<https://fccid.io/HV4DTHW1300>
<https://fccid.io/HV4DTHA1300>
<https://fccid.io/HV4DTK2241>
<https://fccid.io/HV4DTH2242>
<https://fccid.io/HV4DTH2200>
<https://fccid.io/HV4DTK1300>
<https://fccid.io/HV4DTK2200>
<https://fccid.io/HV4DTH2400>
<https://fccid.io/HV4DTK2400>
<https://fccid.io/HV4DTU2235B>
<https://fccid.io/HV4DTF720C>
<https://fccid.io/HV4DTU1631>
<https://fccid.io/HV4DTK2100>
<https://fccid.io/HV4DTU2231A>
<https://fccid.io/HV4DTU2231>
<https://fccid.io/HV4DTF720A>
<https://fccid.io/HV4DTU1931>
<https://fccid.io/HV4DTZ2000W>
<https://fccid.io/HV4DTF521>
<https://fccid.io/HV4DTF720>
<https://fccid.io/HV4DTI520>
<https://fccid.io/HV4DTU710>
<https://fccid.io/HV4PTH460>
<https://fccid.io/HV4PTH860>
<https://fccid.io/HV4PTH660>
<https://fccid.io/HV4PTH851>
<https://fccid.io/HV4PTH651>
<https://fccid.io/HV4PTH451>
<https://fccid.io/HV4PTH850>
<https://fccid.io/HV4PTH650>
<https://fccid.io/HV4PTH450>
<https://fccid.io/HV4PTKW>
<https://fccid.io/HV4PTKL>
<https://fccid.io/HV4PTK>
<https://fccid.io/HV4PTZ>
<https://fccid.io/HV4PTZL>
<https://fccid.io/HV4PTU600>
<https://fccid.io/HV4PL700>
<https://fccid.io/HV4PL800>
<https://fccid.io/HV4PL550>
<https://fccid.io/HV4PL-500>
<https://fccid.io/HV4PL500>
<https://fccid.io/HV4PL400>

<https://fccid.io/HV4PL300>
<https://fccid.io/HV4PL100V1>
<https://fccid.io/HV4PL100V>
<https://fccid.io/HV4GD1212U>
<https://fccid.io/HV4GD0608U>
<https://fccid.io/HV4GD1218U>
<https://fccid.io/HV4GD0912U>
<https://fccid.io/HV4GD0405U>
<https://fccid.io/HV4GD0912A>
<https://fccid.io/HV4GD0405A>
<https://fccid.io/HV4GD0608A>
<https://fccid.io/HV4GD1212R>
<https://fccid.io/HV4GD1218R>
<https://fccid.io/HV4GD0912R>
<https://fccid.io/HV4GD0608R>
<https://fccid.io/HV4GD0405R>
<https://fccid.io/HV4FT0405U>
<https://fccid.io/HV4XD>
<https://fccid.io/HV4SD210L>
<https://fccid.io/HV4SD311E>
<https://fccid.io/HV4SD322E>
<https://fccid.io/HV4SD321E>
<https://fccid.io/HV4SD312E>
<https://fccid.io/HV4SD421E>
<https://fccid.io/HV4SD422E>
<https://fccid.io/HV4SD510C>
<https://fccid.io/HV4SD113L>
<https://fccid.io/HV4SD013L>
<https://fccid.io/HV4SD312L>
<https://fccid.io/HV4SD311L>
<https://fccid.io/HV4SD510B>
<https://fccid.io/HV4SD422A>
<https://fccid.io/HV4SD321A>
<https://fccid.io/HV4SD421A>
<https://fccid.io/HV4SD322A>
<https://fccid.io/HV4UD1825R>
<https://fccid.io/HV4UD1218RE>
<https://fccid.io/HV4UD1218R>
<https://fccid.io/HV4UD1212R>
<https://fccid.io/HV4UD0608R>
<https://fccid.io/HV4UD0608A>
<https://fccid.io/HV4UD1515R>
<https://fccid.io/HV4WKT400>
<https://fccid.io/HV4KT0405RNB23>
<https://fccid.io/HV4KT0405R>
<https://fccid.io/HV4KT0405A>
<http://lowtech-city.org/blog/index.php?e=189>
<http://lowtech-city.org/blog/index.php?e=188>
<http://lowtech-city.org/blog/index.php?e=187>
<http://lowtech-city.org/blog/index.php?e=186>
<http://lowtech-city.org/blog/index.php?e=185>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/ArtPad2.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/ArtPad2pro.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/UD2.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/prepio.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pl250.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pl300.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pens.html>
<https://web.archive.org/web/20010205040300/http://tablet.wacom.co.jp/products/ud/top.html>
<https://web.archive.org/web/20010205021100/http://tablet.wacom.co.jp/products/artpadfun/top.html>
https://web.archive.org/web/20001215051200/http://tablet.wacom.co.jp/products/pl/pl_index.html
<https://web.archive.org/web/20010409192903/http://tablet.wacom.co.jp/products/favo/open.html>
https://web.archive.org/web/20010204061900/http://tablet.wacom.co.jp/products/intuos/intuos_index.html

https://web.archive.org/web/20031003002009/http://tablet.wacom.co.jp/products/intuos2/hardware_top.html

<https://web.archive.org/web/20031001235545/http://tablet.wacom.co.jp/products/cintiq/index.html>

<https://web.archive.org/web/20030807113820/http://tablet.wacom.co.jp/products/favo2/index.html>

- [1] (Wacom One S)
- [2] Wacom One Standard Pen
- [3] (Wacom One Standard Pen)
- [4] BAMBOO FUN CORDLESS MOUSE
- [5] (Wacom One M)
- [6] Wacom One Standard Pen
- [7] (Wacom One Pen)
- [8] Graphire4 cordless mouse
- [9] (Intuos S) (Wacom Intuos, Pen Only Small)
- [10] (Wacom Pen 4K)
- [11] (Dr. Grip Digital for Wacom ブラック) (Dr. Grip Digital for Wacom アクアブルー)
- [12] GRAPHIRE3 CORDLESS MOUSE
- [13] (Intuos BT S) (Wacom Intuos, Pen & Bluetooth Small)
- [14] (Wacom Pen 4K)
- [15] (LAMY AL-Star black EMR Pen)
- [16] GRAPHIRE2 CORDLESS MOUSE
- [17] (Intuos M) (Wacom Intuos, Pen Only Medium)
- [18] (Wacom Pen 4K)
- [19] (STAEDTLER Noris digital classic Stylus)
- [20] GRAPHIRE CORDLESS MOUSE
- [21] (Intuos BT M) (Wacom Intuos, Pen & Bluetooth Medium)
- [22] (Wacom Pen 4K)
- [23] (STAEDTLER Noris digital jumbo Stylus)
- [24] (Intuos Draw Small) (Intuos Small)
- [25] (Wacom Pen 2K)
- [26] (Wacom Pen 4K)
- [27] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)
- [28] INTUOS4 MOUSE

[29] (Intuos Art Small) (Intuos Photo Small) (Intuos Comic Small) (Intuos Touch Small)

[30] (Wacom Pen 2K)

[31] (Wacom Pen 2K)

[32] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[33] INTUOS4 LENS CURSOR

[34] (Intuos Draw Medium) (Intuos Medium)

[35] (Wacom Pen 2K)

[36] (Wacom Pen 2K)

[37] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[38] Intuos3 mouse

[39] (Intuos Art Medium) (Intuos Touch Medium)

[40] (Wacom Pen 2K)

[41] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[42] Intuos3 lens cursor

[43] (Intuos Pen (S)) (Intuos Small) (Intuos Creative Pen Tablet - Small)

[44] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[45] INTUOS2 2D MOUSE

[46] (Intuos Pen & Touch (S)) (Intuos Touch Small) (Intuos Creative Pen & Touch Tablet - Small)

[47] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[48] INTUOS2 4D MOUSE

[49] (Intuos Pen & Touch (M)) (Intuos Medium)

[50] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[51] INTUOS2 LENS CURSOR

[52] (Intuos Pen (M)) (Intuos Touch Medium) (Intuos Creative Pen & Touch Tablet - Medium)

[53] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[54] INTUOS 4D MOUSE

[55] (One by Wacom (S)) (One by Wacom small) (One by Wacom pen tablet)

[56] (Wacom Pen 2K)

[57] (Bamboo Fun CTH Pen)

[58] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[59] INTUOS LENS CURSOR

[60] (One by Wacom (M)) (One by Wacom medium) (One by Wacom pen tablet)

[61] (Wacom Pen 2K)

[62] (Bamboo CTL Pen)

[63] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[64] 4-button cursor

[65] (Bamboo Splash) (One by Wacom (S))

[66] (Bamboo CTH Pen)

[67] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[68] 16 button cursor

[69] (One by Wacom (M))

[70] (Bamboo One Pen)

[71] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[72] Four-Button Cursor

[73] (Bamboo Connect) (Bamboo Pen Tablet)

[74] (Bamboo Pen)

[75] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[76] Four-Button Cursor

[77] (Bamboo Capture) (Bamboo Manga) (Bamboo Comic)

[78] (Bamboo Fun Pen)

[79] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[80] Four-Button Cursor

[81] (Bamboo Create) (Bamboo Fun) (Bamboo Comic)

[82] (Graphire4 Pen)

[83] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[84] Sixteen-Button Cursor

[85] (Bamboo One Pen (S)) (Bamboo One, Small Tablet)

[86] (Bamboo One Pen)

[87] (Bamboo One Pen)

[88] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[89] (Bamboo One Pen (M)) (Bamboo One, Medium Tablet)

[90] (Bamboo One Pen)

[91] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[92] (Bamboo Fun (S)) (Bamboo Craft (S)) (Bamboo Comic Pen & Touch (S)) (Bamboo Pen & Touch Special Edition (S)) (Bamboo Fun Small Tablet) (Bamboo Fun Pen & Touch) (Bamboo Comic Pen & Touch) (Bamboo Tablet)

[93] (Bamboo Fun CTH Pen)

[94] (Graphire3 Inking Pen) (Graphire2 Inking Pen) (Graphire Inking Pen)

[95] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[96] (Bamboo Fun (M)) (Bamboo Comic Pen & Touch (M)) (Bamboo Pen & Touch Special Edition (M)) (Bamboo Fun Medium Tablet) (Bamboo Tablet)

[97] (Bamboo Fun CTH Pen)

[98] (Graphire Pen)

[99] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[100] (Bamboo Pen (S)) (Bamboo Pen Tablet)

[101] (Bamboo CTL Pen)

[102] (Graphire3 Pen)

[103] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[104] (Bamboo Pen & Touch) (Bamboo Pen & Touch) (Bamboo Tablet)

[105] (Bamboo CTH Pen)

[106] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[107] (Bamboo Touch) (Bamboo Touch Tablet) [no emr digitizer]

[108] (LLC Pen)

[109] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[110] (Bamboo Pen (M)) (Bamboo Pen Tablet)

[111] (Graphire2 Pen)

[112] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[113] (Bamboo) (Bamboo Tablet)

[114] (Bamboo Pen)

[115] (Graphire Pen)

[116] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[117] (Bamboo Fun (4x5)) (Small Bamboo Fun Tablet)

[118] (Bamboo Fun Pen)

[119] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[120] (Bamboo Fun (6x8)) (Medium Bamboo Fun Tablet)

[121] (Bamboo Fun Pen)

[122] (PenPartner Pen) (UltraPen)

[123] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[124] (Wacom FAVO Wireless FW-300USB)

[125] (Graphire4 (4x5))

[126] (Graphire4 Pen)

[127] (Wacom Pro Pen 2)

[128] (Graphire4 (6x8))

[129] (Graphire4 Pen)

[130] (Wacom Pro Pen Slim)

[131] (Bamboo Pad USB model, Bamboo Pad Light)

[132] (Wacom Pro Pen 3d)

[133] (Bamboo Pad wireless model)

[134] (Wacom Finetip Pen)

[135] (Graphire3 Pen)

[136] (Wacom Ballpoint Pen)

[137] (Graphire3 (4x5)) (Graphire3 4x5 / A6 Tablet) (F-430)

[138] (Graphire3 Pen)

[139] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[140] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[141] (Graphire Bluetooth Pen Tablet)

[142] (Graphire Pen)

[143] (Intuos4 Grip Pen)

[144] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[145] (Graphire3 (6x8)) (Graphire3 6x8 / A5 Tablet) (F-630)

[146] (Graphire3 Pen)

[147] (Wacom Pro Pen)

[148] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[149] (Bamboo One) (Bamboo One Tablet)

[150] (Intuos4 Airbrush) (Intuos5 Airbrush) (Wacom Airbrush)

[151] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[152] (PenPartner2)

[153] (Intuos4 Inking Pen) (Intuos5 Inking Pen) (Wacom Inking Pen)

[154] (Volito 2 A6)

[155] (Intuos4 Art Pen) (Intuos5 Art Pen) (Wacom Art Pen)

[156] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-

A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[157] (Volito) (PenPartner) (PenStation (2x3))

[158] (Intuos4 Classic Pen) (Intuos5 Classic Pen) (Wacom Classic Pen)

[159] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[160] (Volito) (PenPartner) (PenStation (4x5)) (LLC Tablet)

[161] (LLC Pen)

[162] (Intuos3 Grip Pen)

[163] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[164] (Graphire2 (4x5)) (Graphire2 Tablet) (Graphire2 USB Tablet) (F-410)

[165] (Graphire2 Pen)

[166] (Intuos3 Airbrush)

[167] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[168] (Graphire2 (5x7)) (F-510)

[169] (Intuos3 Art Pen)

[170] (Graphire) (Graphire Tablet) (F-401U) (Wacom FAVO USB)

[171] (Graphire Pen)

[172] (Intuos3 Ink Pen)

[173] (Graphire) (Graphire Tablet)

[174] (Graphire Pen)

[175] (Intuos3 Classic Pen)

[176] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[177] (ARTPAD FAN) (PenParter Tablet)

[178] (PenPartner Pen) (UltraPen)

[179] (Intuos2 Grip Pen)

[180] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[181] (ARTPAD FAN) (PenParter Tablet)

[182] (PenPartner Pen) (UltraPen)

[183] (Intuos2 Airbrush)

[184] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[185] (ARTPAD FAN) (PenParter Tablet)

[186] (PenPartner Pen) (UltraPen)

[187] (Intuos2 Classic Pen)

[188] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[189] (ART Z)

[190] (UltraPen Eraser) (Erasing UltraPen)

[191] (Intuos2 Ink Pen)

[192] (ART Z II)

[193] (UltraPen Eraser) (Erasing UltraPen)

[194] (Intuos2 Stroke Pen)

[195] (ARTPAD II Serial) (ArtPad II A6 Serial)

[196] (UltraPen Eraser) (Erasing UltraPen)

[197] (Intuos Pen)

[198] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[199] (ARTPAD II ADB) (ArtPad II A6 ADB)

[200] (UltraPen Eraser) (Erasing UltraPen)

[201] (Intuos Airbrush)

[202] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[203] (ARTPAD)

[204] (UltraPen Eraser) (Erasing UltraPen)

[205] (Intuos Inking Pen)

[206] (ARTPAD)

[207] (UltraPen Eraser) (Erasing UltraPen)

[208] (Intuos Stroke Pen)

[209] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[210] (UltraPen Eraser) (Erasing UltraPen)

[211] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[212] (Intuos Pro Small) (Wacom Intuos Pro)

[213] (Wacom Pro Pen 2)

[214] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[215] (Intuos Pro Medium) (Wacom Intuos Pro)

[216] (Wacom Pro Pen 2)

[217] Click pen

[218] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[219] (Intuos Pro Large) (Wacom Intuos Pro)

[220] (Wacom Pro Pen 2)

[221] (UltraPen Brush)

[222] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[223] (Intuos pro (S)) (Intuos Pro Professional Pen & Touch Tablet - Small) (Intuos Pro Touch S Tablet) (Intuos Pro Small)

[224] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[225] (UltraPen Pencil)

[226] (Intuos pro (M)) (Intuos Pro Professional Pen & Touch Tablet - Medium) (Intuos Pro Touch M Tablet) (Intuos Pro Medium) (Intuos Pro Medium Special Edition)

[227] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[228] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[229] (Intuos pro (L)) (Intuos Pro Professional Pen & Touch Tablet - Large) (Intuos Pro Touch L Tablet) (Intuos Pro Large)

[230] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[231] (Grip Pen)

[232] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[233] (Intuos5 touch (S)) (Wacom Intuos5 Touch (Small))

[234] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[235] (Grip Pen)

[236] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[237] (Intuos5 (S)) (Wacom Intuos5 (Small))

[238] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[239] (UltraPen 813E)

[240] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[241] (Intuos5 touch (M)) (Wacom Intuos5 Touch (Medium))

[242] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[243] (UltraPen Write)

[244] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[245] (Intuos5 (M)) (Wacom Intuos5 (Medium))

[246] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[247] (UltraPen Write)

[248] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[249] (Intuos5 touch (L)) (Wacom Intuos5 Touch (Large))

[250] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[251] (UltraPen Ink)

[252] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[253] (Intuos4 (4x6)) (Intuos4 S Tablet) (Intuos4 Small) (Intuos4 Special Edition) (Intuos 4 Comic Edition)

[254] (Intuos4 Grip Pen)

[255] (Standard Stylus Gray)

[256] (Intuos4 Wireless) (Intuos4 Wireless Tablet)

[257] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[258] (Standard Stylus Red)

[259] (Intuos4 (6x9)) (Intuos4 M Tablet) (Intuos4 Medium) (Intuos4 Special Edition) (Intuos 4 Comic Edition)

[260] (Intuos4 Grip Pen)

[261] (Slim Stylus Gray)

[262] (Intuos4 (8x13)) (Intuos4 L Tablet) (Intuos4 Large)

[263] (Intuos4 Grip Pen)

[264] (Slim Stylus Magenta)

[265] (Intuos4 (12x19)) (Intuos4 XL Tablet) (Intuos4 Extra Large)

[266] (Intuos4 Grip Pen)

[267] (Pressure Stylus Blue)

[268] (Intuos3 (4x5)) (Intuos3 4x5 / A6 Tablet)

[269] (Intuos3 Grip Pen)

[270] (Pressure Stylus Red)

[271] (Intuos3 (4x6)) (Intuos3 4x6 / A6 Wide Tablet)

[272] (Intuos3 Grip Pen)

[273] (Intuos3 (6x8)) (Intuos3 6x8 / A5 Tablet)

[274] (Intuos3 Grip Pen)

[275] (Intuos3 (6x11)) (Intuos3 6x11 / A5 Wide Tablet)

[276] (Intuos3 Grip Pen)

[277] (Intuos3 (9x12)) (Intuos3 9x12 / A4-Regular Tablet)

[278] (Intuos3 Grip Pen)

[279] (Intuos3 (12x12)) (Intuos3 12x12 / A4 Oversize Tablet)

[280] (Intuos3 Grip Pen)

[281] (Intuos3 (12x19)) (Intuos3 12x19 / A3 Wide Tablet)

[282] (Intuos3 Grip Pen)

[283] Cintiq Partner

[284] (Intuos2 (4x5)) (Intuos2 4x5 / A6 Tablet) (I-420USB)

[285] (Intuos2 Grip Pen)

[286] (Intuos2 (4x5)) (Intuos2 4x5 / A6 Tablet) (I-420Serial)

[287] (Intuos2 Grip Pen)

[288] (Intuos2 (6x8)) (Intuos2 6x8 / A5 Tablet) (I-620USB)

[289] (Intuos2 Grip Pen)

[290] (Intuos2 (6x8)) (Intuos2 6x8 / A5 Tablet) (I-620Serial)

[291] (Intuos2 Grip Pen)

[292] (Intuos2 (9x12)) (Intuos2 9x12 / A4-Regular Tablet) (I-920USB)

[293] (Intuos2 Grip Pen)

[294] (Intuos2 (9x12)) (Intuos2 9x12 / A4-Regular Tablet) (I-920Serial)

[295] (Intuos2 Grip Pen)

[296] (Intuos2 (12x12)) (Intuos2 12x12 / A4-Oversize Tablet) (I-1220USB)

[297] (Intuos2 Grip Pen)

[298] (Intuos2 (12x12)) (Intuos2 12x12 / A4-Oversize Tablet) (I-1220Serial)

[299] (Intuos2 Grip Pen)

[300] (Intuos2 (12x18)) (Intuos2 12x18 / A3 Tablet) (I-1820USB)

[301] (Intuos2 Grip Pen)

[302] (Intuos2 (12x18)) (Intuos2 12x18 / A3 Tablet) (I-1820Serial)

[303] (Intuos2 Grip Pen)

[304] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400USB)

[305] (Intuos Pen)

[306] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400Serial)

[307] (Intuos Pen)

[308] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400ADB)

[309] (Intuos Pen)

[310] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600USB)

[311] (Intuos Pen)

[312] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600Serial)

[313] (Intuos Pen)

[314] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600ADB)

[315] (Intuos Pen)

[316] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900USB)

[317] (Intuos Pen)

[318] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900Serial)

[319] (Intuos Pen)

[320] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900ADB)

[321] (Intuos Pen)

[322] (Intuos (12x12)) (Intuos 12x12 Tablet) (I-1200USB)

[323] (Intuos Pen)

[324] (Intuos (12x12)) (Intuos 12x12 Tablet) (I-1200Serial)

[325] (Intuos Pen)

[326] (Intuos (12x18)) (Intuos 12x18 Tablet) (I-1800USB)

[327] (Intuos Pen)

[328] (Intuos (12x18)) (Intuos 12x18 Tablet) (I-1800Serial)

[329] (Intuos Pen)

[330] (ART Z II)

[331] (UltraPen Eraser) (Erasing UltraPen)

[332] (ART Z II)

[333] (UltraPen Eraser) (Erasing UltraPen)

[334] (ART Z II)

[335] (UltraPen Eraser) (Erasing UltraPen)

[336] (ART Z II)

[337] (UltraPen Eraser) (Erasing UltraPen)

[338] (ART Z II)

[339] (UltraPen Eraser) (Erasing UltraPen)

[340] (ART Z II)

[341] (UltraPen Eraser) (Erasing UltraPen)

[342] (Artpad II Pro Serial) (UltraPad A5 Serial)

[343] (UltraPen Eraser) (Erasing UltraPen)

[344] (Artpad II Pro ADB) (UltraPad A5 ADB)

[345] (UltraPen Eraser) (Erasing UltraPen)

[346] (UD-1212 II) (ULTRAPAD II) (UltraPad A4) (UD-1212-RSR) (UD-1212-RSB)

[347] (UltraPen Eraser) (Erasing UltraPen)

[348] (UD-1218 II / E) (UD-1218 II / S) (ULTRAPAD II) (UltraPad A3) (UD-1218-RER) (UD-1218-RSR)

[349] (UltraPen Eraser) (Erasing UltraPen)

[350] (UD-1825 II) (ULTRAPAD II) (UltraPad A2) (UD-1825-RSR)

[351] (UltraPen Eraser) (Erasing UltraPen)

[352] (Standard 6 x 9)

[353] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[354] (Standard 12 x 12)

[355] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[356] (Electrostatic 12 x 12)

[357] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[358] (Menu Panel 12 x 12)

[359] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[360] (Standard 15 x 15)

[361] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[362] (Electrostatic 15 x 15)

[363] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[364] (Menu Panel 15 x 15)

[365] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[366] (Standard 12 x 18)

[367] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[368] (Electrostatic 12 x 18)

[369] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[370] (Menu Panel 12 x 18)

[371] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[372] (Standard 18 x 25)

[373] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[374] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[375] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)