

Kuuube's Wacom Tablet Mastersheet

Tablets										Pens										Mice									
Tablets										Pens										Mice									
Model	Release Date	Size (mm)	Resolution (DPI)	Pressure Sensitivity (Levels)	Active Area (mm)	Weight (g)	Price (USD)	Features	Notes	Model	Release Date	Size (mm)	Resolution (DPI)	Pressure Sensitivity (Levels)	Active Area (mm)	Weight (g)	Price (USD)	Features	Notes	Model	Release Date	Size (mm)	Resolution (DPI)	Pressure Sensitivity (Levels)	Active Area (mm)	Weight (g)	Price (USD)	Features	Notes
Intuos3 6x9	2004	152x102	5040	1024	140x90	100	150	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 9x12	2004	229x152	5040	1024	210x135	150	250	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 12x18	2004	305x229	5040	1024	285x180	200	350	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 18x26	2004	457x330	5040	1024	425x270	250	550	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 24x36	2004	609x438	5040	1024	575x360	300	850	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 36x48	2004	914x660	5040	1024	855x540	350	1200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 48x60	2004	1219x864	5040	1024	1135x720	400	1500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 60x84	2004	1524x1118	5040	1024	1415x900	450	1800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 84x126	2004	2133x1527	5040	1024	1995x1260	500	2200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 126x188	2004	3175x2381	5040	1024	2975x1800	550	2500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 188x270	2004	4778x3567	5040	1024	4475x2700	600	2800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 270x396	2004	7112x5354	5040	1024	6675x4050	650	3000	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 396x564	2004	10161x7620	5040	1024	9475x5670	700	3200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 564x846	2004	14192x10668	5040	1024	13075x8010	750	3500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 846x1269	2004	21333x15270	5040	1024	19950x12600	800	3800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 1269x1902	2004	31754x23811	5040	1024	29750x18000	850	4000	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 1902x2823	2004	47786x35672	5040	1024	44750x27000	900	4200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 2823x4234	2004	71121x53543	5040	1024	66750x40500	950	4500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 4234x6351	2004	101617x76204	5040	1024	94750x56700	1000	4800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 6351x9527	2004	141922x106685	5040	1024	130750x80100	1050	5000	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 9527x14290	2004	213337x152706	5040	1024	199500x126000	1100	5200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 14290x21426	2004	317542x238117	5040	1024	297500x180000	1150	5500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 21426x32139	2004	477857x356728	5040	1024	447500x270000	1200	5800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 32139x48210	2004	711212x535439	5040	1024	667500x405000	1250	6000	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 48210x72315	2004	1016167x762040	5040	1024	947500x567000	1300	6200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 72315x108472	2004	1419222x1066851	5040	1024	1307500x801000	1350	6500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 108472x162708	2004	2133377x1527062	5040	1024	1995000x1260000	1400	6800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 162708x244062	2004	3175432x2381173	5040	1024	2975000x1800000	1450	7000	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 244062x366093	2004	4778587x3567284	5040	1024	4475000x2700000	1500	7200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 366093x549138	2004	7112142x5354395	5040	1024	6675000x4050000	1550	7500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 549138x823707	2004	10161697x7620406	5040	1024	9475000x5670000	1600	7800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 823707x1235562	2004	14192252x10668517	5040	1024	13075000x8010000	1650	8000	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 1235562x1853343	2004	21333807x15270628	5040	1024	19950000x12600000	1700	8200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 1853343x2780021	2004	31754357x23811739	5040	1024	29750000x18000000	1750	8500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 2780021x4170032	2004	47785907x35672850	5040	1024	44750000x27000000	1800	8800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 4170032x6255048	2004	71121457x53543961	5040	1024	66750000x40500000	1850	9000	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 6255048x9382564	2004	101617007x76204072	5040	1024	94750000x56700000	1900	9200	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 9382564x14073821	2004	141922557x106685183	5040	1024	130750000x80100000	1950	9500	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard
Intuos3 14073821x21110732	2004	213338107x152706294	5040	1024	199500000x126000000	2000	9800	Basic pen tablet with touch strip	Discontinued	Pro Pen 2	2004	127x127	5040	1024	127x127	100	150	Basic pen with eraser and eraser wheel	Standard	Mouse	2004	95x60	3200	3	95x60	100	150	Basic mouse with scroll wheel	Standard

Kuuube's Info

Tablet Sheets and Guides

[Kuuube's Tablet Buying Guide](#)

[Kuuube's Wacom Tablet Mastersheet](#)

[Kuuube's Wacom Tablet Pen Compatibility Mastersheet](#)

[Kuuube's Wacom Pen Nib Guide](#)

Info

If you need to contact me personally, join my discord. I may not reply elsewhere.

[osu! Profile](#)

[Discord Server](#)

[Github](#)

[Youtube](#)

Sources

Not all sources are directly listed. Some information may be found in links or media contained in the pages below.

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq21ux-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq-software-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq20wsx-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq18sx-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq15x-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq12wx-usermanual-final.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-capture-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/intuos5-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-pen-bamboo-touch-bamboo-fun.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-user-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-fun-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos3-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire4-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire3-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos2-users-manual-win.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire2-users-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos-users-manual-mac.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos-users-manual-win.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphiremanual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphireusersmanual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire-bluetooth-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/penpartner-usb-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/penpartner.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dth2242-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dtk2241-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/dtu710-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/dtf720-manual.pdf>

<https://wcm-cdn.wacom.com/events/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/dtf521-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/intuosprosm1-2021updated/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/intuos3-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacomintuos-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacom-intuos-2015-ipi/ipi-en.pdf>

<https://cdn.wacom.com/f/ipi/0x0302/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/onebywacom-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-capture-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/bamboo-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-pen-bamboo-touch-bamboo-fun.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-user-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/bamboo-fun-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire4-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire3-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire-bluetooth-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphire2-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/graphiremanual.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-tablets/wacomintuospro-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos-pro-2017/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos5-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/intuos5-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/intuos4-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/intuos4-wireless-users-manualkr.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/intuos4-users-manualkr.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wcp27/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wacomone-ipi-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/cintiq22-ipi-2021latest/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-displays/wacom-cintiq-pro-24-32ipi-2021/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/cintiq-pro/ipi-en.pdf>

<https://wcm-cdn.wacom.com/-/media/files/downloads/product-support/ipis/pen-computers/mobile-studio-pro/2020/ipi-en.pdf>

<https://cdn.wacom.com/f/ipi/0x0325/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x032B/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x032A/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x0304/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/cintiq-companion-warranty.pdf>

<https://cdn.wacom.com/f/ipi/0x005B/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00F8/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00FA/IPI-EN.pdf>

<https://cdn.wacom.com/f/ipi/0x00F4/IPI-EN.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-warranties/pen-display-tablet-warranty.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq-software-users-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq12wx-usermanual-final.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq21ux-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq15x-user-manual.pdf>

<https://wcm-cdn.wacom.com/-/media/graveyard/wacomdotcom/files/store-manuals/legacy-models/cintiq18sx-user-manual.pdf>

<https://www.manualslib.com/manual/378157/Wacom-Sd-013a.html>

<https://www.manualslib.com/products/Wacom-Sd-210l-719853.html>

<https://www.manualslib.com/products/Wacom-Sd-310e-719843.html>

<https://www.manualslib.com/products/Wacom-Sd-311e-719844.html>

<https://www.manualslib.com/products/Wacom-Sd-312e-719851.html>

<https://www.manualslib.com/products/Wacom-Sd-320e-719845.html>

<https://www.manualslib.com/products/Wacom-Sd-321e-719846.html>

<https://www.manualslib.com/products/Wacom-Sd-322e-719847.html>

<https://www.manualslib.com/products/Wacom-Sd-420e-719848.html>

<https://www.manualslib.com/products/Wacom-Sd-421e-719849.html>

<https://www.manualslib.com/products/Wacom-Sd-422e-719850.html>

<https://www.manualslib.com/products/Wacom-Ctf-221-K-9366610.html>

<https://www.manualslib.com/products/Wacom-Cte-660-8828808.html>

<https://www.manualslib.com/products/Wacom-Cte-460-8828807.html>

<https://www.manualslib.com/products/Wacom-Ct-0405-U-9366374.html>

<https://www.manualslib.com/products/Wacom-Bamboo-Fun-Cth-461-12708124.html>

<https://www.manualslib.com/products/Wacom-Bamboo-Fun-Cth-661-12708125.html>

<https://fccid.io/HV4CTL4100WLA>

<https://fccid.io/HV4CTL6100WLA>

<https://fccid.io/HV4CTL6100WL>

<https://fccid.io/HV4CTL4100WL>

<https://fccid.io/HV4CTL6100>

<https://fccid.io/HV4CTL4100>

<https://fccid.io/HV4CTL672>

<https://fccid.io/HV4CTL472>

<https://fccid.io/HV4CTL671>

<https://fccid.io/HV4CTL471>

<https://fccid.io/HV4CTH690>

<https://fccid.io/HV4CTH490>

<https://fccid.io/HV4CTH301>

<https://fccid.io/HV4CTH300>

<https://fccid.io/HV4CTH680>

<https://fccid.io/HV4CTH480>

<https://fccid.io/HV4CTH670>

<https://fccid.io/HV4CTE660>

<https://fccid.io/HV4CTL-660>

<https://fccid.io/HV4CT0405U>

<https://fccid.io/HV4DTU1141BA>

<https://fccid.io/HV4DTC121>

<https://fccid.io/HV4DTH271>

<https://fccid.io/HV4DTH134>

<https://fccid.io/HV4DTH167>

<https://fccid.io/HV4DTC133>

<https://fccid.io/HV4DTHW1321>

<https://fccid.io/HV4DTU1031AX>

<https://fccid.io/HV4DTK2260>

<https://fccid.io/HV4DTHW1621>

<https://fccid.io/HV4DTK1660>
<https://fccid.io/HV4DTH2420>
<https://fccid.io/HV4DTH3220>
<https://fccid.io/HV4DTK2451>
<https://fccid.io/HV4DTH2452>
<https://fccid.io/HV4DTH1152>
<https://fccid.io/HV4DTU1141B>
<https://fccid.io/HV4DTH1620>
<https://fccid.io/HV4DTH1320>
<https://fccid.io/HV4DTHW1620>
<https://fccid.io/HV4DTHW1320>
<https://fccid.io/HV4DTK1651>
<https://fccid.io/HV4DTU1141>
<https://fccid.io/HV4DTK1301>
<https://fccid.io/HV4DTH1300>
<https://fccid.io/HV4DTK2700>
<https://fccid.io/HV4DTH2700>
<https://fccid.io/HV4DTHW1310>
<https://fccid.io/HV4DTU1031X>
<https://fccid.io/HV4DTU1031>
<https://fccid.io/HV4DTHW1300>
<https://fccid.io/HV4DTHA1300>
<https://fccid.io/HV4DTK2241>
<https://fccid.io/HV4DTH2242>
<https://fccid.io/HV4DTH2200>
<https://fccid.io/HV4DTK1300>
<https://fccid.io/HV4DTK2200>
<https://fccid.io/HV4DTH2400>
<https://fccid.io/HV4DTK2400>
<https://fccid.io/HV4DTU2235B>
<https://fccid.io/HV4DTF720C>
<https://fccid.io/HV4DTU1631>
<https://fccid.io/HV4DTK2100>
<https://fccid.io/HV4DTU2231A>
<https://fccid.io/HV4DTU2231>
<https://fccid.io/HV4DTF720A>
<https://fccid.io/HV4DTU1931>
<https://fccid.io/HV4DTZ2000W>
<https://fccid.io/HV4DTF521>
<https://fccid.io/HV4DTF720>
<https://fccid.io/HV4DTI520>
<https://fccid.io/HV4DTU710>
<https://fccid.io/HV4PTH460>
<https://fccid.io/HV4PTH860>
<https://fccid.io/HV4PTH660>
<https://fccid.io/HV4PTH851>
<https://fccid.io/HV4PTH651>
<https://fccid.io/HV4PTH451>
<https://fccid.io/HV4PTH850>
<https://fccid.io/HV4PTH650>
<https://fccid.io/HV4PTH450>
<https://fccid.io/HV4PTKW>
<https://fccid.io/HV4PTKL>
<https://fccid.io/HV4PTK>
<https://fccid.io/HV4PTZ>
<https://fccid.io/HV4PTZL>
<https://fccid.io/HV4PTU600>
<https://fccid.io/HV4PL700>
<https://fccid.io/HV4PL800>
<https://fccid.io/HV4PL550>
<https://fccid.io/HV4PL-500>
<https://fccid.io/HV4PL500>
<https://fccid.io/HV4PL400>

<https://fccid.io/HV4PL300>
<https://fccid.io/HV4PL100V1>
<https://fccid.io/HV4PL100V>
<https://fccid.io/HV4GD1212U>
<https://fccid.io/HV4GD0608U>
<https://fccid.io/HV4GD1218U>
<https://fccid.io/HV4GD0912U>
<https://fccid.io/HV4GD0405U>
<https://fccid.io/HV4GD0912A>
<https://fccid.io/HV4GD0405A>
<https://fccid.io/HV4GD0608A>
<https://fccid.io/HV4GD1212R>
<https://fccid.io/HV4GD1218R>
<https://fccid.io/HV4GD0912R>
<https://fccid.io/HV4GD0608R>
<https://fccid.io/HV4GD0405R>
<https://fccid.io/HV4FT0405U>
<https://fccid.io/HV4XD>
<https://fccid.io/HV4SD210L>
<https://fccid.io/HV4SD311E>
<https://fccid.io/HV4SD322E>
<https://fccid.io/HV4SD321E>
<https://fccid.io/HV4SD312E>
<https://fccid.io/HV4SD421E>
<https://fccid.io/HV4SD422E>
<https://fccid.io/HV4SD510C>
<https://fccid.io/HV4SD113L>
<https://fccid.io/HV4SD013L>
<https://fccid.io/HV4SD312L>
<https://fccid.io/HV4SD311L>
<https://fccid.io/HV4SD510B>
<https://fccid.io/HV4SD422A>
<https://fccid.io/HV4SD321A>
<https://fccid.io/HV4SD421A>
<https://fccid.io/HV4SD322A>
<https://fccid.io/HV4UD1825R>
<https://fccid.io/HV4UD1218RE>
<https://fccid.io/HV4UD1218R>
<https://fccid.io/HV4UD1212R>
<https://fccid.io/HV4UD0608R>
<https://fccid.io/HV4UD0608A>
<https://fccid.io/HV4UD1515R>
<https://fccid.io/HV4WKT400>
<https://fccid.io/HV4KT0405RNB23>
<https://fccid.io/HV4KT0405R>
<https://fccid.io/HV4KT0405A>
<http://lowtech-city.org/blog/index.php?e=189>
<http://lowtech-city.org/blog/index.php?e=188>
<http://lowtech-city.org/blog/index.php?e=187>
<http://lowtech-city.org/blog/index.php?e=186>
<http://lowtech-city.org/blog/index.php?e=185>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/ArtPad2.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/ArtPad2pro.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/UD2.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/prepio.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pl250.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pl300.html>
<https://web.archive.org/web/19970710015016/http://www.wacom.co.jp/tablet/pens.html>
<https://web.archive.org/web/20010205040300/http://tablet.wacom.co.jp/products/ud/top.html>
<https://web.archive.org/web/20010205021100/http://tablet.wacom.co.jp/products/artpadfun/top.html>
https://web.archive.org/web/20001215051200/http://tablet.wacom.co.jp/products/pl/pl_index.html
<https://web.archive.org/web/20010409192903/http://tablet.wacom.co.jp/products/favo/open.html>
https://web.archive.org/web/20010204061900/http://tablet.wacom.co.jp/products/intuos/intuos_index.html

https://web.archive.org/web/20031003002009/http://tablet.wacom.co.jp/products/intuos2/hardware_top.html

<https://web.archive.org/web/20031001235545/http://tablet.wacom.co.jp/products/cintiq/index.html>

<https://web.archive.org/web/20030807113820/http://tablet.wacom.co.jp/products/favo2/index.html>

- [1] (Wacom One S)
- [2] Wacom One Standard Pen
- [3] (Wacom One Standard Pen)
- [4] BAMBOO FUN CORDLESS MOUSE
- [5] (Wacom One M)
- [6] Wacom One Standard Pen
- [7] (Wacom One Pen)
- [8] Graphire4 cordless mouse
- [9] (Intuos S) (Wacom Intuos, Pen Only Small)
- [10] (Wacom Pen 4K)
- [11] (Dr. Grip Digital for Wacom ブラック) (Dr. Grip Digital for Wacom アクアブルー)
- [12] GRAPHIRE3 CORDLESS MOUSE
- [13] (Intuos BT S) (Wacom Intuos, Pen & Bluetooth Small)
- [14] (Wacom Pen 4K)
- [15] (LAMY AL-Star black EMR Pen)
- [16] GRAPHIRE2 CORDLESS MOUSE
- [17] (Intuos M) (Wacom Intuos, Pen Only Medium)
- [18] (Wacom Pen 4K)
- [19] (STAEDTLER Noris digital classic Stylus)
- [20] GRAPHIRE CORDLESS MOUSE
- [21] (Intuos BT M) (Wacom Intuos, Pen & Bluetooth Medium)
- [22] (Wacom Pen 4K)
- [23] (STAEDTLER Noris digital jumbo Stylus)
- [24] (Intuos Draw Small) (Intuos Small)
- [25] (Wacom Pen 2K)
- [26] (Wacom Pen 4K)
- [27] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)
- [28] INTUOS4 MOUSE

[29] (Intuos Art Small) (Intuos Photo Small) (Intuos Comic Small) (Intuos Touch Small)

[30] (Wacom Pen 2K)

[31] (Wacom Pen 2K)

[32] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[33] INTUOS4 LENS CURSOR

[34] (Intuos Draw Medium) (Intuos Medium)

[35] (Wacom Pen 2K)

[36] (Wacom Pen 2K)

[37] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[38] Intuos3 mouse

[39] (Intuos Art Medium) (Intuos Touch Medium)

[40] (Wacom Pen 2K)

[41] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[42] Intuos3 lens cursor

[43] (Intuos Pen (S)) (Intuos Small) (Intuos Creative Pen Tablet - Small)

[44] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[45] INTUOS2 2D MOUSE

[46] (Intuos Pen & Touch (S)) (Intuos Touch Small) (Intuos Creative Pen & Touch Tablet - Small)

[47] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[48] INTUOS2 4D MOUSE

[49] (Intuos Pen & Touch (M)) (Intuos Medium)

[50] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[51] INTUOS2 LENS CURSOR

[52] (Intuos Pen (M)) (Intuos Touch Medium) (Intuos Creative Pen & Touch Tablet - Medium)

[53] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[54] INTUOS 4D MOUSE

[55] (One by Wacom (S)) (One by Wacom small) (One by Wacom pen tablet)

[56] (Wacom Pen 2K)

[57] (Bamboo Fun CTH Pen)

[58] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[59] INTUOS LENS CURSOR

[60] (One by Wacom (M)) (One by Wacom medium) (One by Wacom pen tablet)

[61] (Wacom Pen 2K)

[62] (Bamboo CTL Pen)

[63] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[64] 4-button cursor

[65] (Bamboo Splash) (One by Wacom (S))

[66] (Bamboo CTH Pen)

[67] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[68] 16 button cursor

[69] (One by Wacom (M))

[70] (Bamboo One Pen)

[71] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[72] Four-Button Cursor

[73] (Bamboo Connect) (Bamboo Pen Tablet)

[74] (Bamboo Pen)

[75] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[76] Four-Button Cursor

[77] (Bamboo Capture) (Bamboo Manga) (Bamboo Comic)

[78] (Bamboo Fun Pen)

[79] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[80] Four-Button Cursor

[81] (Bamboo Create) (Bamboo Fun) (Bamboo Comic)

[82] (Graphire4 Pen)

[83] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[84] Sixteen-Button Cursor

[85] (Bamboo One Pen (S)) (Bamboo One, Small Tablet)

[86] (Bamboo One Pen)

[87] (Bamboo One Pen)

[88] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[89] (Bamboo One Pen (M)) (Bamboo One, Medium Tablet)

[90] (Bamboo One Pen)

[91] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[92] (Bamboo Fun (S)) (Bamboo Craft (S)) (Bamboo Comic Pen & Touch (S)) (Bamboo Pen & Touch Special Edition (S)) (Bamboo Fun Small Tablet) (Bamboo Fun Pen & Touch) (Bamboo Comic Pen & Touch) (Bamboo Tablet)

[93] (Bamboo Fun CTH Pen)

[94] (Graphire3 Inking Pen) (Graphire2 Inking Pen) (Graphire Inking Pen)

[95] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[96] (Bamboo Fun (M)) (Bamboo Comic Pen & Touch (M)) (Bamboo Pen & Touch Special Edition (M)) (Bamboo Fun Medium Tablet) (Bamboo Tablet)

[97] (Bamboo Fun CTH Pen)

[98] (Graphire Pen)

[99] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[100] (Bamboo Pen (S)) (Bamboo Pen Tablet)

[101] (Bamboo CTL Pen)

[102] (Graphire3 Pen)

[103] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[104] (Bamboo Pen & Touch) (Bamboo Pen & Touch) (Bamboo Tablet)

[105] (Bamboo CTH Pen)

[106] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[107] (Bamboo Touch) (Bamboo Touch Tablet) [no emr digitizer]

[108] (LLC Pen)

[109] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[110] (Bamboo Pen (M)) (Bamboo Pen Tablet)

[111] (Graphire2 Pen)

[112] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[113] (Bamboo) (Bamboo Tablet)

[114] (Bamboo Pen)

[115] (Graphire Pen)

[116] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[117] (Bamboo Fun (4x5)) (Small Bamboo Fun Tablet)

[118] (Bamboo Fun Pen)

[119] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[120] (Bamboo Fun (6x8)) (Medium Bamboo Fun Tablet)

[121] (Bamboo Fun Pen)

[122] (PenPartner Pen) (UltraPen)

[123] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[124] (Wacom FAVO Wireless FW-300USB)

[125] (Graphire4 (4x5))

[126] (Graphire4 Pen)

[127] (Wacom Pro Pen 2)

[128] (Graphire4 (6x8))

[129] (Graphire4 Pen)

[130] (Wacom Pro Pen Slim)

[131] (Bamboo Pad USB model, Bamboo Pad Light)

[132] (Wacom Pro Pen 3d)

[133] (Bamboo Pad wireless model)

[134] (Wacom Finetip Pen)

[135] (Graphire3 Pen)

[136] (Wacom Ballpoint Pen)

[137] (Graphire3 (4x5)) (Graphire3 4x5 / A6 Tablet) (F-430)

[138] (Graphire3 Pen)

[139] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[140] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[141] (Graphire Bluetooth Pen Tablet)

[142] (Graphire Pen)

[143] (Intuos4 Grip Pen)

[144] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[145] (Graphire3 (6x8)) (Graphire3 6x8 / A5 Tablet) (F-630)

[146] (Graphire3 Pen)

[147] (Wacom Pro Pen)

[148] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[149] (Bamboo One) (Bamboo One Tablet)

[150] (Intuos4 Airbrush) (Intuos5 Airbrush) (Wacom Airbrush)

[151] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[152] (PenPartner2)

[153] (Intuos4 Inking Pen) (Intuos5 Inking Pen) (Wacom Inking Pen)

[154] (Volito 2 A6)

[155] (Intuos4 Art Pen) (Intuos5 Art Pen) (Wacom Art Pen)

[156] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-

A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[157] (Volito) (PenPartner) (PenStation (2x3))

[158] (Intuos4 Classic Pen) (Intuos5 Classic Pen) (Wacom Classic Pen)

[159] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[160] (Volito) (PenPartner) (PenStation (4x5)) (LLC Tablet)

[161] (LLC Pen)

[162] (Intuos3 Grip Pen)

[163] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[164] (Graphire2 (4x5)) (Graphire2 Tablet) (Graphire2 USB Tablet) (F-410)

[165] (Graphire2 Pen)

[166] (Intuos3 Airbrush)

[167] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[168] (Graphire2 (5x7)) (F-510)

[169] (Intuos3 Art Pen)

[170] (Graphire) (Graphire Tablet) (F-401U) (Wacom FAVO USB)

[171] (Graphire Pen)

[172] (Intuos3 Ink Pen)

[173] (Graphire) (Graphire Tablet)

[174] (Graphire Pen)

[175] (Intuos3 Classic Pen)

[176] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[177] (ARTPAD FAN) (PenParter Tablet)

[178] (PenPartner Pen) (UltraPen)

[179] (Intuos2 Grip Pen)

[180] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[181] (ARTPAD FAN) (PenParter Tablet)

[182] (PenPartner Pen) (UltraPen)

[183] (Intuos2 Airbrush)

[184] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[185] (ARTPAD FAN) (PenParter Tablet)

[186] (PenPartner Pen) (UltraPen)

[187] (Intuos2 Classic Pen)

[188] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[189] (ART Z)

[190] (UltraPen Eraser) (Erasing UltraPen)

[191] (Intuos2 Ink Pen)

[192] (ART Z II)

[193] (UltraPen Eraser) (Erasing UltraPen)

[194] (Intuos2 Stroke Pen)

[195] (ARTPAD II Serial) (ArtPad II A6 Serial)

[196] (UltraPen Eraser) (Erasing UltraPen)

[197] (Intuos Pen)

[198] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[199] (ARTPAD II ADB) (ArtPad II A6 ADB)

[200] (UltraPen Eraser) (Erasing UltraPen)

[201] (Intuos Airbrush)

[202] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[203] (ARTPAD)

[204] (UltraPen Eraser) (Erasing UltraPen)

[205] (Intuos Inking Pen)

[206] (ARTPAD)

[207] (UltraPen Eraser) (Erasing UltraPen)

[208] (Intuos Stroke Pen)

[209] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[210] (UltraPen Eraser) (Erasing UltraPen)

[211] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[212] (Intuos Pro Small) (Wacom Intuos Pro)

[213] (Wacom Pro Pen 2)

[214] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[215] (Intuos Pro Medium) (Wacom Intuos Pro)

[216] (Wacom Pro Pen 2)

[217] Click pen

[218] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[219] (Intuos Pro Large) (Wacom Intuos Pro)

[220] (Wacom Pro Pen 2)

[221] (UltraPen Brush)

[222] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[223] (Intuos pro (S)) (Intuos Pro Professional Pen & Touch Tablet - Small) (Intuos Pro Touch S Tablet) (Intuos Pro Small)

[224] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[225] (UltraPen Pencil)

[226] (Intuos pro (M)) (Intuos Pro Professional Pen & Touch Tablet - Medium) (Intuos Pro Touch M Tablet) (Intuos Pro Medium) (Intuos Pro Medium Special Edition)

[227] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[228] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[229] (Intuos pro (L)) (Intuos Pro Professional Pen & Touch Tablet - Large) (Intuos Pro Touch L Tablet) (Intuos Pro Large)

[230] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[231] (Grip Pen)

[232] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[233] (Intuos5 touch (S)) (Wacom Intuos5 Touch (Small))

[234] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[235] (Grip Pen)

[236] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[237] (Intuos5 (S)) (Wacom Intuos5 (Small))

[238] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[239] (UltraPen 813E)

[240] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[241] (Intuos5 touch (M)) (Wacom Intuos5 Touch (Medium))

[242] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[243] (UltraPen Write)

[244] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[245] (Intuos5 (M)) (Wacom Intuos5 (Medium))

[246] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[247] (UltraPen Write)

[248] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[249] (Intuos5 touch (L)) (Wacom Intuos5 Touch (Large))

[250] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[251] (UltraPen Ink)

[252] (ACK-20401K, ACK-20101W, ACK-20014, FUZ-A141, FUZ-A010, FUZ-A010-03, FUZ-A121, FUZ-A154, FUZ-A120, PSI-A034, PSI-A007, PSI-A043, PSI-A042, PSI-A066, PSI-A011, PSI-A021)

[253] (Intuos4 (4x6)) (Intuos4 S Tablet) (Intuos4 Small) (Intuos4 Special Edition) (Intuos 4 Comic Edition)

[254] (Intuos4 Grip Pen)

[255] (Standard Stylus Gray)

[256] (Intuos4 Wireless) (Intuos4 Wireless Tablet)

[257] (Intuos4 Grip Pen) (Intuos5 Grip Pen) (Wacom Grip Pen)

[258] (Standard Stylus Red)

[259] (Intuos4 (6x9)) (Intuos4 M Tablet) (Intuos4 Medium) (Intuos4 Special Edition) (Intuos 4 Comic Edition)

[260] (Intuos4 Grip Pen)

[261] (Slim Stylus Gray)

[262] (Intuos4 (8x13)) (Intuos4 L Tablet) (Intuos4 Large)

[263] (Intuos4 Grip Pen)

[264] (Slim Stylus Magenta)

[265] (Intuos4 (12x19)) (Intuos4 XL Tablet) (Intuos4 Extra Large)

[266] (Intuos4 Grip Pen)

[267] (Pressure Stylus Blue)

[268] (Intuos3 (4x5)) (Intuos3 4x5 / A6 Tablet)

[269] (Intuos3 Grip Pen)

[270] (Pressure Stylus Red)

[271] (Intuos3 (4x6)) (Intuos3 4x6 / A6 Wide Tablet)

[272] (Intuos3 Grip Pen)

[273] (Intuos3 (6x8)) (Intuos3 6x8 / A5 Tablet)

[274] (Intuos3 Grip Pen)

[275] (Intuos3 (6x11)) (Intuos3 6x11 / A5 Wide Tablet)

[276] (Intuos3 Grip Pen)

[277] (Intuos3 (9x12)) (Intuos3 9x12 / A4-Regular Tablet)

[278] (Intuos3 Grip Pen)

[279] (Intuos3 (12x12)) (Intuos3 12x12 / A4 Oversize Tablet)

[280] (Intuos3 Grip Pen)

[281] (Intuos3 (12x19)) (Intuos3 12x19 / A3 Wide Tablet)

[282] (Intuos3 Grip Pen)

[283] Cintiq Partner

[284] (Intuos2 (4x5)) (Intuos2 4x5 / A6 Tablet) (I-420USB)

[285] (Intuos2 Grip Pen)

[286] (Intuos2 (4x5)) (Intuos2 4x5 / A6 Tablet) (I-420Serial)

[287] (Intuos2 Grip Pen)

[288] (Intuos2 (6x8)) (Intuos2 6x8 / A5 Tablet) (I-620USB)

[289] (Intuos2 Grip Pen)

[290] (Intuos2 (6x8)) (Intuos2 6x8 / A5 Tablet) (I-620Serial)

[291] (Intuos2 Grip Pen)

[292] (Intuos2 (9x12)) (Intuos2 9x12 / A4-Regular Tablet) (I-920USB)

[293] (Intuos2 Grip Pen)

[294] (Intuos2 (9x12)) (Intuos2 9x12 / A4-Regular Tablet) (I-920Serial)

[295] (Intuos2 Grip Pen)

[296] (Intuos2 (12x12)) (Intuos2 12x12 / A4-Oversize Tablet) (I-1220USB)

[297] (Intuos2 Grip Pen)

[298] (Intuos2 (12x12)) (Intuos2 12x12 / A4-Oversize Tablet) (I-1220Serial)

[299] (Intuos2 Grip Pen)

[300] (Intuos2 (12x18)) (Intuos2 12x18 / A3 Tablet) (I-1820USB)

[301] (Intuos2 Grip Pen)

[302] (Intuos2 (12x18)) (Intuos2 12x18 / A3 Tablet) (I-1820Serial)

[303] (Intuos2 Grip Pen)

[304] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400USB)

[305] (Intuos Pen)

[306] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400Serial)

[307] (Intuos Pen)

[308] (Intuos (4x5)) (Intuos 4x5 Tablet) (I-400ADB)

[309] (Intuos Pen)

[310] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600USB)

[311] (Intuos Pen)

[312] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600Serial)

[313] (Intuos Pen)

[314] (Intuos (6x8)) (Intuos 6x8 Tablet) (I-600ADB)

[315] (Intuos Pen)

[316] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900USB)

[317] (Intuos Pen)

[318] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900Serial)

[319] (Intuos Pen)

[320] (Intuos (9x12)) (Intuos 9x12 Tablet) (I-900ADB)

[321] (Intuos Pen)

[322] (Intuos (12x12)) (Intuos 12x12 Tablet) (I-1200USB)

[323] (Intuos Pen)

[324] (Intuos (12x12)) (Intuos 12x12 Tablet) (I-1200Serial)

[325] (Intuos Pen)

[326] (Intuos (12x18)) (Intuos 12x18 Tablet) (I-1800USB)

[327] (Intuos Pen)

[328] (Intuos (12x18)) (Intuos 12x18 Tablet) (I-1800Serial)

[329] (Intuos Pen)

[330] (ART Z II)

[331] (UltraPen Eraser) (Erasing UltraPen)

[332] (ART Z II)

[333] (UltraPen Eraser) (Erasing UltraPen)

[334] (ART Z II)

[335] (UltraPen Eraser) (Erasing UltraPen)

[336] (ART Z II)

[337] (UltraPen Eraser) (Erasing UltraPen)

[338] (ART Z II)

[339] (UltraPen Eraser) (Erasing UltraPen)

[340] (ART Z II)

[341] (UltraPen Eraser) (Erasing UltraPen)

[342] (Artpad II Pro Serial) (UltraPad A5 Serial)

[343] (UltraPen Eraser) (Erasing UltraPen)

[344] (Artpad II Pro ADB) (UltraPad A5 ADB)

[345] (UltraPen Eraser) (Erasing UltraPen)

[346] (UD-1212 II) (ULTRAPAD II) (UltraPad A4) (UD-1212-RSR) (UD-1212-RSB)

[347] (UltraPen Eraser) (Erasing UltraPen)

[348] (UD-1218 II / E) (UD-1218 II / S) (ULTRAPAD II) (UltraPad A3) (UD-1218-RER) (UD-1218-RSR)

[349] (UltraPen Eraser) (Erasing UltraPen)

[350] (UD-1825 II) (ULTRAPAD II) (UltraPad A2) (UD-1825-RSR)

[351] (UltraPen Eraser) (Erasing UltraPen)

[352] (Standard 6 x 9)

[353] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[354] (Standard 12 x 12)

[355] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[356] (Electrostatic 12 x 12)

[357] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[358] (Menu Panel 12 x 12)

[359] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[360] (Standard 15 x 15)

[361] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[362] (Electrostatic 15 x 15)

[363] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[364] (Menu Panel 15 x 15)

[365] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[366] (Standard 12 x 18)

[367] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[368] (Electrostatic 12 x 18)

[369] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[370] (Menu Panel 12 x 18)

[371] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[372] (Standard 18 x 25)

[373] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[374] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)

[375] (Standard Stylus), (Standard Stylus), (Slim Stylus), (Slim Stylus), (Pressure Stylus), (Pressure Stylus)