


MODUL 3

WIFI, BRIDGE (PRAKTEK ALAT)


Berlian Edra / L200164013

1. Setting Wifi untuk Accespoint :


Masuk ke menu konfigurasi dengan address 192.168.1.254 (defaultnya 192.168.1.50)




Memilih opsi sebagai accespoint dan mengganti IP addressnya



Memberi IP di PC dengan network yang sama dengan accespoint



Tes ping ke IP dari accespoint teman



2. Pont-to-Point

Masuk ke menu konfigurasi dengan address 192.168.1.1

192.168.1.1/setup.cgi

Not secure | 192.168.1.1/setup.cgi

Apps

EnGenius® Wireless Outdoor Access Point/ Client Bridge

Client Bridge

- Status
 - Main
 - Connection Status
 - System Log
- System
 - System Properties
 - IP Settings
 - Spanning Tree Settings
- Wireless
 - Wireless Network
 - Wireless Security
 - Wireless Advanced Settings
- Management
 - Administration
 - SNMP Settings
 - Auto Reboot Settings
 - Backup/Restore Settings
 - Firmware Upgrade
 - Time Settings
 - Log
 - Diagnostics

Wireless Network

Home Reset

Wireless Mode: 802.11b/g Mixed (2GHz/54Mbps)

SSID: Specify the static SSID : ROZAQUE TEAM (1 to 32 characters)
Or press the button to search for any available WLAN Service.

Site Survey

Prefer BSSID: ☐ E8 ☐ DE ☐ 27 ☐ B7 ☐ F6 ☐ 78

WDS Client: ☒ Enable ☐ Disable

Apply Cancel

Beri IP satu network dengan accespoint sebelumnya

192.168.1.1/setup.cgi

Not secure | 192.168.1.1/setup.cgi

Apps

EnGenius® Wireless Outdoor Access Point/ Client Bridge

Client Bridge

- Status
 - Main
 - Connection Status
 - System Log
- System
 - System Properties
 - IP Settings
 - Spanning Tree Settings
- Wireless
 - Wireless Network
 - Wireless Security
 - Wireless Advanced Settings
- Management
 - Administration
 - SNMP Settings
 - Auto Reboot Settings
 - Backup/Restore Settings
 - Firmware Upgrade
 - Time Settings
 - Log
 - Diagnostics

System Information

Device Name	EOC2611P
Ethernet MAC Address	00:02:6f:94:4d:e6
Wireless MAC Address	00:02:6f:94:4d:e7
Country	N/A
Current Time	Sat Jan 1 07:43:06 UTC 2000
Device Uptime	0 Days 0 Hours 43 Mins
Firmware Version	1.3.1
Auto Reboot Settings	Disabled

LAN Settings


IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0
DHCP Client	Disabled

Current Wireless Settings


Operation Mode	Client Bridge
Wireless Mode	IEEE 802.11b/g Mixed
Frequency/Channel	2.412GHz (Channel 01)
Wireless Network Name (SSID)	ROZAQUE TEAM
Security	Disabled
Spanning Tree Protocol	Disabled
Distance	1 Km

Refresh

Pilih mode ClientBridge



Beri IP satu network dengan point-to-point sebelumnya



Tes ping ke IP dari accespoint teman

