

<b>DTC</b>	<b>C1289 / 41</b>	<b>VGRS Malfunction</b>
------------	-------------------	-------------------------

## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1289 / 41	VGRS control system is abnormal.	VGRS control system

## INSPECTION PROCEDURE

<b>1</b>	<b>Check the DTC for the VGRS (<a href="#">See page DI-185</a>).</b>
----------	--

**\*<sup>1</sup>**

**Repair VGRS control system according to the code output.**

**\*<sup>2</sup>**

**Check for ECU connected to malfunction indicator light.**

\*<sup>1</sup>: Output NG code

\*<sup>2</sup>: Malfunction indicator light remains ON