



PARTS LOCATION



Engine Room R/B
□ EFI Fuse

Transponder Key ECU



Cowl Side J/B LH
□ IGN Fuse

DLC3

H

I26015