


REPLACEMENT

1. REMOVE COMPANION FLANGE DUST DEFLECTOR

Using SST a steel plate and press, remove the dust deflector.
SST 09950 -00020



2. INSTALL DUST DEFLECTOR

Using SST a steel plate and press, install a new dust deflector.
SST 09726 -40010