

GlowCore v2.0

Quick Start Guide

Learn how to get started
with your GlowCore dev board.




Download PDF:
bit.ly/3gZ5Wep

IO33/ B1	GPIO 33	Button 1	ADC1
IO4/ B2	GPIO 4	Button 2	ADC2
IO5/ B3	GPIO 5	Button 3	
IO26/ B4	GPIO 26	Button 4	ADC2
IO16/ LED1 0	GPIO 16	LED 1 DATA OUT	
IO17/ LED2 0	GPIO 17	LED 2 DATA OUT	
IO12/ TDI	GPIO 12	MTDI	ADC2
IO13/ TCK	GPIO 13	MTCK	ADC2
IO14/ TMS	GPIO 14	MTMS	ADC2


Step 1:

Connect your LED strip to GlowCore. Check out the pinout overview (PDF available via bit.ly/3P3ZSO1) for more details.



Step 2:

Power GlowCore via **USB-C** or connect an external 5V source to the **5V IN** pin.



Step 3:

Connect to Wi-Fi:



 **GlowCore**

Control GlowCore via your web browser or the WLED app, using the **IP 4.3.2.1**