

2_3. Y-AxisRailAssembly


Materials			
Electronic Parts	Frame Parts	Hardware Parts	Fasteners Parts
	Y-Axi rail (2080V-520mm) *2	GT2 Timing Belt *2 (75cm*2)	M3 Screw*4
		Belt-Tensioner *4	M3 Square nut *4



[Step1] Install Y-Axis rail into y-carriage aluminum. (The specifications of Y-Axis rail and workbench are the same, there are threaded holes at both ends of the Y-Axis rail.)



Adjust the tightness of the guide rail, turn the eccentric column with a wrench to change the eccentric position of the eccentric column.



[Step2] Install the Y-Axis GT2 Timing Belt in the same way as the X-Axis, as shown in the figure.

