



Fix Your Stuff

Community

Store

USD ▾

/

EN

Join

Log In

Free Shipping on Domestic Orders \$75+

Home > Appliance > Washing Machine > Samsung Washing Machine

Parts

Guides

Troubleshooting

Edit



How to Clean a Samsung DC68 Washing Machine Filter



Ishmeet Cheema and 5 other contributors

Last updated on Dec 13, 2024

180K

60

42

3

5 - 10 minutes

Easy

What you need

Tools



Scissors

\$5.59 ~~\$6.99~~

★★★★★ 4.9

[View](#)



Paper Towels

Affiliate link

Available for sale on Amazon

[Show more...](#)

[Go to step 1 ↓](#)

Introduction

This guide shows you how to clean the filter of your Samsung Washing Machine (Model DC68-02807A-03) to ensure your washer lasts longer and works more effectively.

A washing machine filter traps all sorts of dust, lint, and loose hair from your clothes. However, over time as the filter accumulates all this unwanted stuff and is not cleaned out regularly, your machine will function less effectively and clothes won't be washed properly. If your washing machine is not working and cleaning your clothes as well as it should, the most common reason is that your filter needs to be cleaned.

Before spending money on repairing your machine, check to see if your filter is free of debris. Often just regularly maintaining and cleaning out your filter ensures that your washing machine works as well as it should!

Note: Samsung recommends cleaning the filter once every two months.

Step 1 How to Clean a Samsung DC68 Washing Machine Filter



- Turn the washing machine off and locate the filter access door.
- ④ Most Samsung washing machine filters are located at the front. Sometimes they will have a sticker on them to communicate filter cleanliness best practices.

 Add a comment

Step 2



- Gently press the top of the filter door to release and open it.
- ④ If that doesn't work, use the handle of a small pair of scissors or something similar to push down and open the access door.

 1 comment

Step 3

How to Clean a Samsung DC68 Washing Machine Filter: step 3, image 1 of 1

- Place a rag underneath your access door and place a basin on top.

 Add a comment

Meet Your New Repair Assistant

AI repair help built on real-world fixes

Try FixBot Now



Step 4

How to Clean a Samsung DC68 Washing Machine Filter: step 4, image 1 of 3



- Pull out the drain hose and unplug the white cap to let the excess water flow out into the basin.


 7 comments

Step 5

How to Clean a Samsung DC68 Washing Machine Filter: step 5, image 1 of 2



- Once the water stops coming out from the drain hose, secure it back into position.

 Add a comment

Step 6

How to Clean a Samsung DC68 Washing Machine Filter: step 6, image 1 of 3



- Push the filter in and twist it counterclockwise.
- Remove the filter from the filter bay.

 [12 comments](#)

Step 7

How to Clean a Samsung DC68 Washing Machine Filter: step 7, image 1 of 2



- Remove any debris from the filter using a paper towel.
- Rinse the filter under warm water.

 [2 comments](#)

Step 8

How to Clean a Samsung DC68 Washing Machine Filter: step 8, image 1 of 3



- Insert the filter back and secure it by twisting it clockwise.

 [Add a comment](#)

Step 9

How to Clean a Samsung DC68 Washing Machine Filter: step 9, image 1 of 2




- Close the access door by pushing against the machine until you hear a click sound.

 [12 comments](#)



CONCLUSION


You are all done!

 [Give the author +30 points!](#)

42 other people completed this guide.

Gear Up For Future Repairs


[Shop all](#)



Mako Driver Kit - 64 Precision Bits

★★★★★ 775

\$39.95



Pro Tech Toolkit

★★★★★ 2523

\$74.95



Prying and Opening Tool Assortment

★★★★★ 299


\$9.95

Add to cart

Add to cart

Add to cart

Author



Ishmeet Cheema

Member since: 09/19/20

1,239 Reputation

1 Guide authored

with 5 other contributors

Badges: 12



+9 more badges

Team



York University, Team S1-G100, Woodhouse Fall 2020

YORK-WOODHOUSE-F20S1G100

1 Member

5 Guides authored

26 GUIDE COMMENTS

 Add a comment



Thanks.....
can you share where the filter is located on the
Samsung model DC68-03049A-01.

[ampekarek](#) - Aug 1, 2022

Hi! I apologize for the late reply, but I believe the filter for this model would be
located inside the spin basket probably at the back. Here is the link to the
model description and location of the filter [https://www.manualslib.com/
manual/147786....](https://www.manualslib.com/manual/147786....) Hope this helps!

[Ishmeet Cheema](#) - Aug 30, 2023



It worked! Thank you!
[Lisa Cowley](#) - Sep 2, 2022



Hi, thank you for this useful information. How often should the filter be replaced
and how to order thank you
[Ana Perucho](#) - Sep 2, 2022



I can not get the cap off the drain hose. Any suggestions. I have tried twisting and
pulling and it just won't come off
[Christine Watkins](#) - Feb 3, 2023

▼ Load more comments

Add Comment

Post comment

 View Statistics:

Past 24 Hours: 75

Past 7 Days: 429

Past 30 Days: 2,053

All Time: 179,694