

- * Create Part inside Product
- * Product → named XYZYZ
- * Go into Part Design
- * Open Reference Element Toolbar
- * Make Planes
- * Tools → Options → Infrastructure → Part Infrastructure
→ Display → check parameters → OKay
- * Parameters created in Part Level not Product level
- * Formula function → New parameter → length → single value → Apply
- * Parameters ~~should~~ should appear in specification tree
- * In Plane definition → offset → "=" → enter → select parameter
- * To edit formulas → right click on offset → formula → type changes

TXID: 2V21281408052032P
Osiifchin Timothy
tosifchin3@gmail.com

Assignment # : 02 25 22

Date : 02 / 20 / 20

