






These are jumpers to allow the usb and eth power supplies to be disconnected if you don't need them. This seems to actually stop the board from booting though so they might be removed in the next revision.



Sheet: /		
File: breadbee.sch		
Title:		
Size: A3	Date:	Rev:
KiCad E.D.A. kicad 5.1.2+dfsg1-1		Id: 1/1