



+ - CON3
 + - CON2
 + - CON1
 - Vbat_L_Current
 + VBAT_L_Current
 + - VARSUPPLY
 Def. 12V
 + - CON4
 + - SERVOsupply



BFMC POWER BOARD V3

