


NOTES:

1. RELATIVE HOLE SPACING IS CRITICAL
2. ENSURE CBORE NOT TOO DEEP
3. FOR REWORK DO NOT ASSUME AXES ARE PARALLEL TO PLATE



Drawn: A. Kofman 2022-01-28
 Checked: C. Schuster 2022-01-28
 Contact: Alexander Kofman
 (646) 538-6195

Default Tolerances:
 X.X: ± 0.050
 X.XX: ± 0.010
 Angles: $\pm 1^\circ$

QTY: 1

SCALE: 1:2

MATERIAL

0.5" 6061 Al Plate

TITLE: Front Control Arm Jig

SIZE

A

UW -MADISON PART NUMBER


JIG-211-01-22-A

ALL UNITS ARE INCHES

SHEET 1 OF 2

NOTES:

1. FOR REWORK DO NOT ASSUME AXES ARE PARALLEL TO PLATE



Drawn: A. Kofman 2022-01-28
Checked: C. Schuster 2022-01-28
Contact:

Default Tolerances:
X.X: ± 0.050
X.XX: ± 0.010
Angles: $\pm 1^\circ$

QTY: 1

SCALE: 1:2

TITLE: Front Control Arm Jig Plate

MATERIAL

0.5" 6061 Plate

SIZE UW -MADISON PART NUMBER
A JIG-211-01-22-A

ALL UNITS ARE INCHES

SHEET 2 OF 2