


# Stepper mount Left & Right


Hardware and extra info on last page



Dept.	Technical reference	Created by DutchDude	21/03/2021	Approved by
		Document type	Document status	
		Title Stepper mounts	DWG No.	
		Rev.	Date of issue	Sheet 1/7

# Stepper mount LEFT top view


Hardware and extra info on last page



Dept.	Technical reference	Created by DutchDude 21/03/2021	Approved by	
		Document type	Document status	
		Title Stepper mounts	DWG No.	
			Rev.	Date of issue
			Sheet 2/7	

# Stepper mount LEFT Back view


Hardware and extra info on last page



Dept.	Technical reference	Created by <b>DutchDude</b>	21/03/2021	Approved by
		Document type	Document status	
		Title <b>Stepper mounts</b>	DWG No.	
		Rev.	Date of issue	Sheet <b>3/7</b>

# Stepper mount LEFT SIDE view


Hardware and extra info on last page



Dept.	Technical reference	Created by <b>DutchDude</b>	21/03/2021		Approved by
		Document type		Document status	
		Title <b>Stepper mounts</b>		DWG No.	
		Rev.	Date of issue		Sheet <b>4/7</b>

# Stepper mount LEFT bottom view

Hardware and extra info on last page



Dept.	Technical reference	Created by DutchDude	21/03/2021	Approved by
		Document type	Document status	
		Title Stepper mounts	DWG No.	
		Rev.	Date of issue	Sheet 5/7

# Stepper mount Right


Hardware and extra info on last page

ADDITIONAL INFO - MUST READ

The right stepper mount uses the exact same hardware as the left stepper mount.

OPTIONAL

Installation of the cable chain mount onto the NEMA17 stepper is fully optional.



Dept.	Technical reference	Created by DutchDude	21/03/2021	Approved by
		Document type	Document status	
		Title Stepper mounts	DWG No.	
		Rev.	Date of issue	Sheet 6/7


H A R D W A R E

- 8 - M5X50 BOLTS (INTO T-NUTS)
- 8 - T-NUTS (FOR EXTRUSION)
- 6 - M3X20 (ATTACHES STEPPER)
- 4 - M5X30 Dowell Pins (FOR FLANGE BEARINGS)
- 12 - M5 1MM SPACER (BETWEEN FLANGE BEARINGS)
- 12 - 625RS 5\*16\*5mm (FLANGE BEARING)

E X T R A   I N F O

Sometimes dowell pins don't fit perfectly. To fix this issue you'll need a drill that fits the dowell pin and then using sandpaper, sand them down a little at a time testing fitting until they are a snug fit.

The image below shows a flange stack



Discord:  
<https://discord.com/invite/gzJP2s8>

Dept.	Technical reference	Created by DutchDude      21/03/2021	Approved by		
		Document type	Document status		
		Title Stepper mounts	DWG No.		
			Rev.	Date of issue	Sheet 7/7