



HARDWARE FOR EACH STEPPER MOUNT (In total it's x2!)

- 4 - M5X50 BOLTS (INTO T-NUTS)
- 4 - T-NUTS (FOR EXTRUSION)
- 3 - M3X20 (ATTACHES STEPPER)
- 3 - M5X30 Dowell Pins (FOR FLANGE BEARINGS)
- 6 - M5 1MM SPACER (BETWEEN FLANGE BEARINGS)
- 6 - 625RS 5*16*5mm (FLANGE BEARING)

Dept.		Technical reference		Created by		Approved by	
				DutchDude		21/03/2021	
		Document type		Title		Document status	
				Stepper mounts - Flang bearing		DWG No.	
				Rev.		Date of issue	
						Sheet	
						1/1	