

Print / Right top plate

Print / Left top plate


Print / Left bottom plate

Print / Right bottom plate

- HARDWARE FOR EACH STEPPER MOUNT (In total it's x2!)**
- 4 - M5X50 BOLTS (INTO T-NUTS)
  - 4 - T-NUTS (FOR EXTRUSION)
  - 3 - M3X20 (ATTACHES STEPPER)
  - 2 - M5X30 Dowell Pins (FOR FLANGE BEARINGS)
  - 6 - M5 1MM SPACER (BETWEEN FLANGE BEARINGS)
  - 6 - 625RS 5\*16\*5mm (FLANGE BEARING)

EXTRA INFO

Sometimes dowell pins don't fit perfectly. To fix this issue you'll need a drill to attaches the dowell pin in and sandpaper to sand them down a little. Test fit them into the flange bearings before installation.



m5x30  
DOWELL PIN

Dept.		Technical reference		Created by		Approved by	
				DutchDude		21/03/2021	
		Document type		Document status			
		Title		DWG No.			
		Stepper mounts - Flang bearing					
		Rev.		Date of issue		Sheet	
						1/1	