



A CREE COMPANY

# Cree\_Wlfspd\_ADS Model Kit Installation


RF Modeling Team

07/21/2020




# Installation Instructions – Unzip Model Kit

- Download Cree\_Wlfspd\_ADS\_vx\_x.zip file from portal
- Unzip model kit with windows unzip utility by right clicking the zip file and select “Extract All”.




# Installation Instructions – Unzip Model Kit

- You can also unzip the model kit using ADS drop down menu "unzip design kit"





# Installation Instructions – Add Model Kit Library

- Add the Cree\_Wlfspd\_ADS model kit library to existing workspace by clicking on Design Kit → Manage Libraries → Add Library Definition Files



# Installation Instructions – Add Model Kit Library



# Installation Instructions – Locate Model Palette

- Locate Cree\_Wlfspd\_ADS model kit models on the palette. Scroll down for more available product models. Click on the selected model and drop it in schematic for simulation setup.

