

6

5

4

3


2

1

## Weather Deck on Ship:


## Note:

1. Wireless Calibration System is setup to control up to four Downriggers at one time.
2. Locate Downriggers and control boxes in accordance with standard calibration procedures.



Typical Downrigger Setup: Up to 4 Downriggers and Control Boxes can be remotely controlled.


## Acoustics Lab: (Interior of Ship)



## Various Locations on Ship:

## Note:

1. Mount XBee-PRO routers throughout the ship to extend the wireless range of the calibration system.
2. Any number of Routers can be used.



File: EchoCAL\_SystemWiringDiagRevA.tcw

NOAA/NMFS, Northeast Fisheries Science Center 166 Water Street Woods Hole, MA 02543			
TITLE EchoCAL Wireless Calibration System System Block Wiring Diagram			
SIZE A3	CAGE CODE	DWG NO ECHOAL-10000	REV A
SCALE N/A		SHEET 1 of 1	

6

5

4

3

2

1