


PLISN: BAWL
PCCN: W9E215
SCC: 00002
FSC: 5925

REV	ECO	BY	DATE	A	B	C	D	E	F	G
This engineering drawing (CAD / CAM or otherwise) is the proprietary property of Square D Company, not part of any published or unpublished information, and is to be used for furnishing information to others, or used directly or indirectly, in any way detrimental to the interest of Square D Company and is to be returned upon request by Square D Company. All Rights Reserved.										Square D Company 1988



WARNING

HAZARD OF PERSONAL INJURY OR EQUIPMENT DAMAGE.
BEFORE PERFORMING ANY MAINTENANCE OR REPAIR WORK:
- ALWAYS REMOVE THE CIRCUIT BREAKER COMPLETELY FROM THE CELL.
- PRESS OPEN, CLOSE, AND OPEN PUSHBUTTONS TO DISCHARGE ALL SPRINGS.
FAILURE TO OBSERVE THESE PRECAUTIONS CAN CAUSE DEATH OR SEVERE PERSONAL INJURY!

TOOLS REQUIRED:

- 7/16 WRENCH (FRONT COVER)
- 13mm WRENCH (FRONT COVER)

INSTRUCTIONS:

- 1) REMOVE FRONT COVER.
- 2) LOCATE ANTI-PUMP RELAY ABOVE AUXILIARY SWITCH.
- 3) REMOVE BY LIFTING RETAINING CLIP AND BY PULLING RELAY OUT OF SOCKET.
- 4) INSTALL NEW ANTI-PUMP RELAY INTO EXISTING SOCKET. SECURE BY PLACING RETAINING CLIP OVER RELAY.
- 5) INSTALL FRONT COVER.
- 6) APPLY CONTROL VOLTAGE TO VERIFY PROPER OPERATION.

STANDARD TOLERANCE UNLESS OTHERWISE SPECIFIED	LINEAR DIMENSIONS	ONE PLACE DECIMAL ± .060	DESIGN LOC: WC	USED ON: VR BREAKERS	ECO: .	PRINTS TO: -- -- -- -- --	 SQUARE D COMPANY POWER EQUIPMENT	
	TWO PLACE DECIMAL ± .030	DRAWN BY: BSM	RAWSTOCK: ----	DATE: 12/20/13	TITLE: ANTI-PUMP RELAY, 120VAC	QTY: -		
	THREE PLACE DECIMAL ± .015	CHKD BY: BSM	MATERIAL DESCRIPTION: ----	SCALE: 1 / 2	PART# 46040-477-53			
	HOLE DIMENSIONS	PUNCHED/DRILLED ± .005	ENGINEER: BSM	FINISH DESCRIPTION: ----				
	DIMENSIONED ± .1° UNDIMENSIONED 90° ± .2°						B 46040-477-53	REV *