

FLIGHT *Control* – Installation

1. Insert ACD Software License Key Dongle in USB port.
2. Locate the installer file “ACD_FLIGHTControl_Setup_4.0.0.0.exe”
3. Double-click on ‘ACD_FLIGHTControl_Setup_4.0.0.0.exe’ and follow instructions.
4. After completion Launch Matlab (R2021b).
5. Navigate to C:\FLIGHTControl or to the location of the installation.
6. Run FLIGHTcontrol.p in Matlab command window.
7. Restart Matlab after shortcut is created automatically. If this is the first time installing a FLIGHT product, you will be prompted to restart Matlab so the java class path can be updated. When asked please close Matlab.
8. Open Matlab and you will see “FLIGHTcontrol” in your ‘Favourites’ area at the top of the screen.
9. Launch FLIGHTcontrol Software using the Shortcut.