







1. Create 3D model of the different parts and make the Assembly of the Roller Support as given below.

	<table border="1"> <thead> <tr> <th>Item No</th> <th>Part No</th> <th>Qty</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Base</td> <td>1</td> </tr> <tr> <td>2</td> <td>Bracket</td> <td>2</td> </tr> <tr> <td>3</td> <td>Roller</td> <td>1</td> </tr> <tr> <td>4</td> <td>Bush</td> <td>5</td> </tr> <tr> <td>5</td> <td>Shaft</td> <td>1</td> </tr> <tr> <td>6</td> <td>DIN 7984 M12x20. 14.7N</td> <td>4</td> </tr> </tbody> </table>	Item No	Part No	Qty	1	Base	1	2	Bracket	2	3	Roller	1	4	Bush	5	5	Shaft	1	6	DIN 7984 M12x20. 14.7N	4
Item No	Part No	Qty																				
1	Base	1																				
2	Bracket	2																				
3	Roller	1																				
4	Bush	5																				
5	Shaft	1																				
6	DIN 7984 M12x20. 14.7N	4																				
																						
																						
	<p><b>Part 6</b> is DIN 7984 M12x20. 14.7N is a standard part that can be found from the "insert 3D..Design Library"</p>																					