

PLANES Users Guide

Olivier DAZEL
LAUM UMR CNRS 6613
olivier.dazel@univ-lemans.fr

January 2, 2017

Contents

1	General overview	5
1.1	Presentation	5
1.2	General organisation	5
1.2.1	Labels for materials	5
1.2.2	Type of boundaries	6
1.2.3	Models for elements	7
2	How to use the Multilayer solver	9
3	How to use the FEM/DGM solver	11
4	Benchmarks	13
4.1	Kundt Tube	13


Chapter 1

General overview

1.1 Presentation

PLANES (Porous LAum NumErical Simulator) project is a collection of Matlab/Fortran scripts to simulate the vibroacoustics response of coupled systems including acoustic, elastic, porous materials, PML...

1.2 General organisation



All the information relative to a project are in the **Projects** folder. As a user, you do not need (theoretically) to modify the files in the other folders.

1.2.1 Labels for materials

The convention is as follows:

- 0 AIR
- 1XXX Elastic medium
- 2XXX Equivalent fluid (rigid frame) material
- 3XXX Limp model
- 4XXX Poroelastic Material (or FEM: 1998 formulation)
- 5XXX BIOT (or FEM: 2001 formulation)
- 80xy PML x and y boolean direction

1.2.2 Type of boundaries

- 1 RIGID WALL
- 2 UNIT PRESSURE (FLUID)
- 3 UNIT NORMAL VELOCITY
- 4 UNIT TANGENTIAL VELOCITY
- 5 SLIDING (PEM)
- 6 BONDED (PEM) or CLAMPED (elastic)
- 7 UNIT PRESSURE (PEM)
- 8 UNIT NORMAL VELOCITY (PEM)
- 9 UNIT NORMAL VELOCITY (PEM)
- 10 INCIDENT AIR PLANE WAVE on ACOUSTIC/Biot98 ELEMENT
- 11 INCIDENT AIR PLANE WAVE on ELASTIC ELEMENT
- 12 INCIDENT AIR PLANE WAVE on Biot2001 ELEMENT
- 13 DtN Plate
- 20 TRANSMITTED AIR PLANE WAVE on ACOUSTIC/Biot98 ELEMENT
- 21 TRANSMITTED AIR PLANE WAVE on ELASTIC ELEMENT
- 21 TRANSMITTED AIR PLANE WAVE on Biot2001 ELEMENT
- 30 UNIT PRESSURE WAVE for dispersion analysis¹

¹use `data_model.theta_inc` for incidence angle.

- 60 UNIT NORMAL VELOCITY on H12 with FLUX APPLICATION
- 61 DGM RADIATIVE BOUNDARY
- 98 PERIODICITY LEFT
- 99 PERIODICITY RIGHT
- 4xx ZOD impair/pair
- 400 FSI
- 1xyz Excitation wave 1 angle xyz in degree(PEM)
- 2xyz Excitation wave 2 angle xyz in degree(PEM)
- 3xyz Excitation wave 3 angle xyz in degree(PEM)
- 500 VELOCITY DIFFRACION CYLINDRE EF

1.2.3 Models for elements

- 1 TR6
- 2 H12
- 3 TR3
- 10 DGM on TR
- 11 DGM on H

Chapter 2

How to use the Multilayer solver

The Multilayer solver can be launched with a call

```
PLANES_Multilayer(Name,Number,data_model,multilayer_1,frequency)
```

- **Name** is a string associated to the name of the project. This string is the same than the folder in The project area.
- **Number** is an integer. This is the number of the subproject
- **data_model** is a structure that contains the data of the model. In the present case, it only contains the angle of incidence.
- **multilayer** is a structure array which contains one or several multilayer structures. It is associated to several arrays
 - `multilayer.nb(1,#m)` correspond to the number of layer of multilayer structure **#m**.
 - `multilayer.termination(1,#m)` correspond to the termination condition of multilayer structure **#m**. The value is 0 for rigid backing and 1 for a radiation condition
 - `multilayer.d(#1,#m)` correspond to the thickness of the layer **#1** of multilayer structure **#m**. It is a real number.
 - `multilayer.mat(#1,#m)` correspond to the material of the layer **#1** of multilayer structure **#m**. The label is an integer associated to the convention presented in section [1.2.1](#).
- **data_model** is a structure that contains the data of the model. In the present case, it only contains the angle of incidence. It can be either a real number or an array of two real numbers.

- **frequency** is the structure associated to frequency

The result of the Multilayer solver is a File:

Name of the project_#subproject.PW

It is a text file in which each line has $1 + 6l$ columns. The first one correspond to the frequency. The remaining $6l$ columns correspond to the result for multilayer structure $\#l$ and are ordered

- Absorption coefficient
- Real part of the reflexion coefficient
- Imaginary part of the reflexion coefficient
- Transmission loss
- Real part of the transmission coefficient
- Imaginary part of the transmission coefficient

Chapter 3

How to use the FEM/DGM solver

The result of the Multilayer solver is a File:

Name of the project_#subproject.PL

Chapter 4

Benchmarks

4.1 Kundt Tube

Sous projets

- 0: TR6
- 1: H12
- 2: TR6/H12
- 3: DGM on TR
- 4: DGM on H
- 5: DGM on TR / DGM on H
- 6: H12 / DGM on H
- 7: TR6 / DGM on H




Figure 4.1: caption