


PHOTO 1








PHOTO 4

REMOVE THIS HOSE AND
FIT TO P2 ON GENERATOR
MANIFOLD. FIT NEW
HOSE FROM HERE TO P1
ON GENERATOR
MANIFOLD.
SEE PHOTO 3



PHOTO 2




PHOTO 3

P2 PRESSURE OUT
FIT HOSE THAT YOU HAVE
TAKEN OFF HIGH
PRESSURE FILTER. SEE
PHOTO 4

T1 TANK RETURN
FIT NEW HOSE 43 1/2" LONG TO CASE
DRAIN.
SEE PHOTO 5 & 6

P1 PRESSURE IN
FIT NEW HOSE 31 1/2" LONG
TO HIGH PRESSURE FILTER.
SEE PHOTO 4




PHOTO 6

PLEASE MAKE SURE THAT THE
NEW HOSE IS PUT IN THE RIGHT
PLACE AS SHOWN