


General settings


These are valid for all new or opened existing drawings.

Make a folder for working with AutoCAD. For example: F12


Red A and options:




1. Files: automatic save file location: you can find here a file with sv\$ extension after accidental program interruptions or power outage / blackout. After renaming this to a dwg file, you can open it.




2. (Display: crosshair size & color scheme: light / dark & Color....: display colors in different contexts)
3. Open and save: save as & automatic save



4. User preferences: right-click customization



5. Drafting: display Auto Snap aperture box & Auto Snap marker size & Aperture size: it is the impact area of the mouse searching for snap points & ignore hatch objects & ignore dimension extension lines



6. (Selection: pick box size & grip size)

Don't forget to click OK!