



\* Trim potentiometer on the rear of the module sets the initial frequency of the oscillator. Assembled modules are calibrated by Midiverse Modular prior to being shipped.

