

Use countersink tool to countersink the holes marked \oplus
Tip: Start with one hole and progressively remove material until M3 bolt head sits flush with the surface

Countersinking must be performed on the correct side
Arrange piece to match this hole arrangement
(The gap between the left-middle and middle-right hole are not equal)

