



Use countersink tool to countersink the holes marked  $\oplus$   
Tip: Start with one hole and progressively remove material until M3 bolt head sits flush with the surface  
It does not matter which side of the piece you countersink