



Use countersink tool to countersink the holes marked \oplus

Tip: Start with one hole and progressively remove material until M3 bolt head sits flush with the surface

It does not matter which side of the piece you countersink