


Push in brass inserts, split end first

Tip: Push in partially with finger, then press against a hard, flat surface



Motor box corner piece assembly