

# Action Glossary

Descriptions for the list of actions.

---

## Overview

Each of the 16 messages can be programmed to match an action.

## Press

A single tap to the switch.

## Release

Releasing the switch after a Press action.

## Long Press

A single tap to the switch that is held down for at least 600ms.

## Long Press Release

Releasing the switch after a Long Press action.

## Double Tap

A double consecutive tap to the switch.

## Double Tap Release

Releasing the switch after a Double Tap action.

## Long Double Tap

A double consecutive tap to the switch that is held down for at least 600ms.

# Long Double Tap Release

Releasing the switch after a Long Double Tap action.

## Release All

This action groups Release and Long Press Release together.