

Action Glossary

Descriptions for the list of actions.

Overview

Each of the 16 messages can be programmed to match an action.

Press

A single tap to the switch.

Release

Releasing the switch after a Press action.

Long Press

A single tap to the switch that is held down for at least 600ms.

Long Press Release

Releasing the switch after a Long Press action.

Double Tap

A double consecutive tap to the switch.

Double Tap Release

Releasing the switch after a Double Tap action.

Long Double Tap

A double consecutive tap to the switch that is held down for at least 600ms.

Long Double Tap Release

Releasing the switch after a Long Double Tap action.

Release All

This action groups Release and Long Press Release together.

© 2018 MorningstarFX Pte Ltd

Documentation built with MkDocs (<http://www.mkdocs.org/>).