

HAZUS Building Attribute Rulesets - Wind - HUEFHS-M-L

Note: Defaults should be assigned to all HUEFHS-M-L Buildings as defined below; then rulesets should be applied to override those defaults as informed by available data.

Essential Facility Classes: Hospitals (small - HUEFHS, medium - HUEFHM, large - HUEFHL)

Typology Assumption: Modeled after small, medium, and large commercial steel buildings.

RoofCvr			Roof Cover
Valid Entries	BUR, SPM	Input Variable	YearBuiltNJDEP
Default	SPM	Input Variable Source	Custom Inventory
Years Ruleset Applies	Ruleset	Notes	Possible Extensions
YearBuiltNJDEP >= 1975	RoofCvr = SPM	<p>NJ Building Code Section 1507 (in particular 1507.10 and 1507.12) address Built Up Roofs and Single Ply Membranes. However, the NJ Building Code only addresses installation and material standards of different roof covers, but not in what circumstance each must be used.</p> <p>SPMs started being used in the 1960s, but different types continued to be developed through the 1980s. Today, single ply membrane roofing is the most popular flat roof option. BURs have been used for over 100 years, and although they are still used today, they are used less than SPMs. Since there is no available ruleset to be taken from the NJ Building Code, the ruleset is based off this information.</p> <p>Sources: https://www.spri.org/2019/01/singe-ply-roofing-101/, https://continuingeducation.bnppmedia.com/courses/johns-manville/understanding-single-ply-roofing-systems/</p> <p>Assumptions of the Ruleset: All flat roofs built before 1975 are BURs. SPMs were developed in the 1960s, and considering that there is a time lag to start consistently using new methods, SPMs rose in importance through the 1970s, becoming more popular. This ruleset assumes that all roofs built after 1975 are SPMs.</p>	Any data from NJ on practices around BUR, SPM should be incorporated; trends presently inferred from when a technology entered the market
YearBuiltNJDEP < 1975	RoofCvr = BUR	<p>NJ Building Code Section 1507 (in particular 1507.10 and 1507.12) address Built Up Roofs and Single Ply Membranes. However, the NJ Building Code only addresses installation and material standards of different roof covers, but not in what circumstance each must be used.</p> <p>SPMs started being used in the 1960s, but different types continued to be developed through the 1980s. Today, single ply membrane roofing is the most popular flat roof option. BURs have been used for over 100 years, and although they are still used today, they are used less than SPMs. Since there is no available ruleset to be taken from the NJ Building Code, the ruleset is based off this information.</p> <p>Sources: https://www.spri.org/2019/01/singe-ply-roofing-101/, https://continuingeducation.bnppmedia.com/courses/johns-manville/understanding-single-ply-roofing-systems/</p> <p>Assumptions of the Ruleset: All flat roofs built before 1975 are BURs. SPMs were developed in the 1960s, and considering that there is a time lag to start consistently using new methods, SPMs rose in importance through the 1970s, becoming more popular. This ruleset assumes that all roofs built after 1975 are SPMs.</p>	Any data from NJ on practices around BUR, SPM should be incorporated; trends presently inferred from when a technology entered the market
shutters			
Valid Entries	yes, no	Input Variable	YearBuiltNJDEP, WBD
Default	yes	Input Variable Source	Custom Inventory

Years Ruleset Applies	Ruleset	Notes	Possible Extensions
All YearBuiltNJDEP	IF WBD = yes, shutters = yes IF WBD = no, shutters, no	Shutters were not required by code until the 2000 IBC. Before 2000, the percentage of commercial buildings that have shutters is assumed to be 46%. This value is based on a study on preparedness of small businesses for hurricane disasters, which says that in Sarasota County, 46% of business owners had taken action to wind-proof or flood-proof their facilities. In addition to that, 46% of business owners reported boarding up their businesses before Hurricane Katrina. In addition, compliance rates based on the Homeowners Survey data hover between 43 and 50 percent. However, it is assumed since this is a hospital, its windows are protected if its in a WBD zone, regardless of year of construction. Source: https://www.sciencedirect.com/science/article/pii/S2212420916303855	Further refine if more specific data is available
WindDebris			<i>wind Debris sources</i>
Valid Entries	A, B, C, D	Input Variable	YearBuiltNJDEP
Default	A	Input Variable Source	
Years Ruleset Applies	Ruleset	Notes	Possible Extensions
YearBuiltNJDEP ≤ Current Year	WindDebris=A	If a building is a given class, according to zoning, neighboring buildings are likely of this class. Thus this assignment is made based on OccupancyClass. We cannot assign "varies by direction" because we don't have specific information. Assume hospitals are in a hybrid commercial, residential area.	Note essential facilities attributes were defined as A, B, C, D which are respectively equivalent to the attributes used for non-essential classes as follows: A: Res/Comm B: Varies by Direction C: Residential D: None
Metal-RDA			<i>Metal Roof Deck Attachment</i>
Valid Entries	standard, superior	Input Variable	YearBuiltNJDEP, DSWII
Default	standard	Input Variable Source	Custom Inventory
Years Ruleset Applies	Ruleset	Notes	Possible Extensions

YearBuiltNJDEP > 2000	<p>IF DSWII ≤ 142 mph, Metal-RDA = standard IF DSWII > 142 mph, Metal-RDA = superior</p>	<p>Present to 2006: 1507.2.8.1 High Wind Attachment. Underlayment applied in areas subject to high winds (Vasd greater than 110 mph as determined in accordance with Section 1609.3.1) shall be applied with corrosion-resistant fasteners in accordance with the manufacturer's instructions. Fasteners are to be applied along the overlap not more than 36 inches on center. Underlayment installed where Vasd, in accordance with section 1609.3.1 equals or exceeds 120 mph shall be attached in a grid pattern of 12 inches between side laps with a 6-inch spacing at the side laps.</p> <p>1507.2.8.1 High Wind Attachment. Underlayment applied in areas subject to high winds (Vasd greater than 110 mph as determined in accordance with Section 1609.3.1) shall be applied with corrosion-resistant fasteners in accordance with the manufacturer's instructions. Fasteners are to be applied along the overlap not more than 36 inches on center. Underlayment installed where Vasd, in accordance with section 1609.3.1 equals or exceeds 120 mph shall be attached in a grid pattern of 12 inches between side laps with a 6-inch spacing at the side laps.</p> <p>1507.2.8.1 High Wind Attachment. Underlayment applied in areas subject to high winds (Vasd greater than 110 mph as determined in accordance with Section 1609.3.1) shall be applied with corrosion-resistant fasteners in accordance with the manufacturer's instructions. Fasteners are to be applied along the overlap not more than 36 inches on center. Underlayment installed where Vasd, in accordance with section 1609.3.1 equals or exceeds 120 mph shall be attached in a grid pattern of 12 inches between side laps with a 6-inch spacing at the side laps.</p> <p>2000-2006: 1507.2.8.1 High Wind Attachment. Underlayment applied in areas subject to high winds (greater than 110 mph) shall be applied with corrosion-resistant fasteners in accordance with the manufacturer's instructions. Fasteners are to be applied along the overlap not more than 36 inches on center. According to Figure 1609, this is basic wind speed.</p> <p>convert Vasd to Vult using $Vasd = \sqrt{0.6} Vult$ --- 110 -> 142</p>	
YearBuiltNJDEP ≤ 2000	Metal-RDA = standard	<p>There is no mention of straps or enhanced tie-downs of any kind in the BOCA codes, and there is no description of these adoptions in IBHS reports or the New Jersey Construction Code Communicator.</p> <p>Although there is no explicit information, it seems that hurricane straps really only came into effect in Florida after Hurricane Andrew (1992), and likely it took several years for these changes to happen. Because Florida is the leader in adopting hurricane protection measures into codes and because there is no mention of shutters or straps in the BOCA codes, it is assumed that New Jersey did not adopt these standards until the 2000 IBC. https://www.insurancejournal.com/news/southeast/2007/05/18/79827.htm https://forum.nachi.org/t/hurricane-straps/4617 http://www.floridaretrofits.com/service/hurricaneStrapsClips</p> <p>Thus, all connections before 2000 are assumed to be standard.</p>	