

## STANDARD DEPARTURE CHART-INSTRUMENT

RJFZ / TSUIKI

SID and TRANSITION

NAKATSU REVERSAL TWO DEPARTURE

RWY 07 : Turn right....

RWY 25 : Turn left within 3NM....

....Climb via TQT R-150 within 20NM of TQT TACAN, turn(direction specified by ATC), reverse course to TQT TACAN, then proceed as directed by ATC.

Cross TQT TACAN at assigned or specified altitude. (MCA at TQT TACAN 6,000ft)

Note : Minimum rate of climb

JET....400ft/NM until passing 2,800ft(RWY25)

PROP....340ft/NM until passing 2,800ft(RWY25)

KANMO TRANSITION

After TQT TACAN, proceed via TQT R-350 to KANMO(TQT R-350/8.6DME), then proceed as directed by ATC.

MINNE TRANSITION

After TQT TACAN, proceed via TQT R-026 to MINNE, then via MIT R-177 to MIT TACAN.

OGORI TRANSITION

After TQT TACAN, proceed via TQT R-239 to OGORI(TQT R-239/39.1DME), then proceed as directed by ATC.

Cross TQT 15DME at or above 7,000ft.