

## STANDARD DEPARTURE CHART - INSTRUMENT

RJNH / HAMAMATSU

SID

KOWA FIVE DEPARTURE

RWY27 : Turn left,...

RWY09 : Turn right,...

....climb via LHT R220 to LHT 39DME, then turn right to intercept and proceed via  
XMT R168 to XMT TACAN.

Maintain 6000FT or below until LHT 10DME,

Cross XMT 27DME / LHT R232 at or above 13000FT.

Note: Before establishing on SID, to avoid fly over populated area, maintain RWY  
HDG until 3NM from RWY end, then take off RWY 27, turn left (take off RWY 09,  
turn right) heading 190 degrees until 8DME from LHT TACAN, then follow SID.

CHANGE : PROC renamed. PROC course.

