

## STANDARD ARRIVAL CHART -INSTRUMENT

RJGG / CHUBU CENTRAIR

STAR RWY18

NORTH ARC ARRIVAL

From over CARDS, via CBE R224, turn left, via CBE 21.0DME clockwise ARC, turn right....  
 From over CHESS, via CBE R339 turn left, via CBE 21.0DME clockwise ARC, turn right....  
 From over SWING, via CBE R042 turn right, via CBE 21.0DME counterclockwise ARC, turn left....  
 From over SLIDE, via CBE R055 turn right, via CBE 21.0DME counterclockwise ARC, turn left....  
 From over TRIKE, via CBE R105 turn right, via CBE 21.0DME counterclockwise ARC, turn left....  
 From over BIWWA, via CBE R307 turn left, via CBE 21.0DME clockwise ARC, turn right....

for ILS Z RWY18 and LOC Z RWY18 :

....to intercept and proceed via ICY-LOC to QUEST.

Cross CBE R330 at or above 6000FT, (when started from CARDS or BIWWA)

Cross ICY 17.8DME at or above 4100FT, cross QUEST at or above 4000FT.

for VOR RWY18 :

....to intercept and proceed via CBE R357 to POKER.

Cross CBE R330 at or above 6000FT, (when started from CARDS or BIWWA)

Cross CBE R357/18.5DME at or above 4100FT, cross POKER at or above 4000FT.

CHANGE : Correction of misdescription(CBE)

