


INSTRUMENT APPROACH CHART

RJSS / SENDAI


VOR RWY27



MISSED APPROACH

Turn left, climb via SDE R160 to 3000FT,
turn left, direct to SDE VOR/DME
and hold.
Contact SENDAI APP.

Timing not authorized for defining the MAPt.



MINIMA		THR elev. 15	AD elev. 6	
CAT			CIRCLING	
	MDA(H)	RVR/ CMV	MDA(H)	VIS
A	390 (384)	900	530 (524)	1600
B		1000		
C				2400
D		1400	560 (554)	3200