

STANDARD ARRIVAL CHART-INSTRUMENT


RJSS / SENDAI

RNAV STAR RWY27

LANCE EAST BRAVO ARRIVAL	Basic RNP1
--------------------------	------------

Note GNSS required.

VAR 8°W (2014)



LANCE EAST BRAVO ARRIVAL

From LANCE at or above 11000FT, to FUBOU at or above 6000FT, to SNOOK at or above 4000FT.

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	LANCE	—	—	-7.8	—	—	+11000	—	—	Basic RNP1
002	TF	FUBOU	—	085 (077.2)	-7.8	5.9	—	+6000	—	—	Basic RNP1
003	TF	SNOOK	—	085 (077.3)	-7.8	15.4	—	+4000	—	—	Basic RNP1