


RJAZ / KOZUSHIMA

AD CHART



INTENTIONALLY LEFT BLANK

STANDARD DEPARTURE CHART-INSTRUMENT



STANDARD DEPARTURE CHART-INSTRUMENT

RJAZ / KOZUSHIMA

RNAV SID

KOZU ONE DEPARTURE

RWY11

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance(NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	112 (105.2)	-7.1	—	—	+1800	—	—	Basic RNP1
002	DF	XAC	—	—	-7.1	—	L	—	—	—	Basic RNP1

RWY29


Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance(NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	292 (285.2)	-7.1	—	—	+1700	—	—	Basic RNP1
002	DF	XAC	—	—	-7.1	—	R	—	—	—	Basic RNP1

CHANGE : New PROC

INSTRUMENT APPROACH CHART

RJAZ / KOZUSHIMA

RNAV (GNSS) RWY11



INSTRUMENT APPROACH CHART

RJAZ / KOZUSHIMA

RNAV (GNSS) RWY29



RJAZ / KOZUSHIMA

Visual REP



Call sign	BRG / DIST from ARP	Remarks
10NM N	360°/10.0NM	海上 Over the sea
赤 崎 Akasaki	009°/ 3.1NM	岬 Cape
祇 苗 島 Tadanaejima	076°/ 3.1NM	島 Island
10NM SE	135°/10.0NM	海上 Over the sea

Call IZU REMOTE on 124.3MHz

RJAZ / KOZUSHIMA

Minimum Vectoring Altitude CHART

